



# WM3500 Decal Placement Guide




- 052274 Decal, LT300 2005 Head/Air Box
- P12879 Decal, Re-Sharp
- 033254 Decal, Moving Parts Danger
- 034801 Decal, Inspect Blade Warning
- 034803 Decal, Blade Guide Info (Large)
- 016834 Decal, Safety Stripe
- 076275 Decal, WM3500 Logo
- 076273 Decal, Wood-Mizer Logo w/Stripes
- 042673 Decal, No Step Caution





- S11753 Decal, Eye/Ear Protection Warning
- 042674 Decal, Transducer Adjustment Caution
- 074077 Decal, 27" White Wood-Mizer Logo
- 052287 Decal, Wood-Mizer Logo 10.25"
- S20097 Decal, Motor Direction
- S20038 Plate, Name
- 016834 Decal, Safety Stripe

**WM3500 Decal Placement Guide**



S09851 Decal, Keep Away Danger  
 S20038 Plate, Name






052275 Decal, Control Panel 2005 Main  
 052276 Decal, Control Panel 2005 Bottom  
 034802 Decal, Blade Guide Info




S20061 Decal, Electrical Hazard Danger  
 076275 Decal, WM3500 Logo  
 076273 Decal, Wood-Mizer Logo w/Stripes


## WM3500 Decal Placement Guide



S12825 Decal, Hydraulic Fluid Replacement  
(Located on Hydraulic Module)



042674 Decal, Transducer Adjustment Caution  
(Located on Right Joystick)



042676 Decal, Cab Option Voltage  
(Located on Disconnect Switch  
inside Cab Option Only)