2.2 Overall Dimensions (Rev. B1.00+)

See Figure 2-2. The overall dimensions of the 12-Foot Log Infeed Deck (LD12) are shown below. Use the LD12 for LT30/40/60/70 model sawmills




FIG. 2-2

Operation & Setup LD01doc021716 2-2

See Figure 2-3. The overall dimensions of the 12-Foot Log Infeed Deck (LD12-1) are shown below. Use the LD12-1 for LT300, WM3000 and WM3500 model sawmills.




FIG. 2-3

See Figure 2-4. The overall dimensions of the 20-Foot Log Infeed Deck (LD20) are shown. Use the LD20 for LT30/40/60/70 model sawmills.




FIG. 2-4

Operation & Setup LD01doc021716 2-4

See Figure 2-5. The overall dimensions of the 20-Foot Log Infeed Deck (LD20-1) are shown. Use the LD20-1 for LT300, WM3000 and WM3500 model sawmills.




FIG. 2-5

2.3 Overall Dimensions (Rev. A1.00 - A2.03)

See Figure 2-6. The overall dimensions of the 12-Foot Log Infeed Deck (LD12) are shown below. Use the LD12 for LT30/40/60/70 model sawmills




FIG. 2-6

Operation & Setup LD01doc021716 2-6

2

See Figure 2-7. The overall dimensions of the 12-Foot Log Infeed Deck (LD12-1) are shown below. Use the LD12-1 for LT300, WM3000 and WM3500 model sawmills.




FIG. 2-7

See Figure 2-8. The overall dimensions of the 20-Foot Log Infeed Deck (LD20) are shown. Use the LD20 for LT30/40/60/70 model sawmills.




FIG. 2-8

2

See Figure 2-9. The overall dimensions of the 20-Foot Log Infeed Deck (LD20-1) are shown. Use the LD20-1 for LT300, WM3000 and WM3500 model sawmills.




FIG. 2-9