

Wood-Mizer[®] Sawmill

Parts Manual

LT35HD

rev. A1.00 - A6.13



Safety is our #1 concern! Read and understand all safety information and instructions before operating, setting up or maintaining this machine.

October 2010

Form #1722

California
Proposition 65 Warning



WARNING: Breathing gas/diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Always start and operate the engine in a well-ventilated area.
If in an enclosed area, vent the exhaust to the outside.
Do not modify or tamper with the exhaust system.
Do not idle the engine except as necessary.

For more information go to **www.P65warnings.ca.gov**.



WARNING: Drilling, sawing, sanding or machining wood products can expose you to wood dust, a substance known to the State of California to cause cancer. Avoid inhaling wood dust or use a dust mask or other safeguards for personal protection.

For more information go to **www.P65Warnings.ca.gov/wood**.

Active Patents assigned to Wood-Mizer, LLC

Wood-Mizer, LLC has received patents that protect our inventions which are a result of a dedication to research, innovation, development, and design. Learn more at: woodmizer.com/patents

©2024 Wood-Mizer LLC

Printed in the United States of America, all rights reserved. No part of this manual may be reproduced in any form by any photographic, electronic, mechanical or other means or used in any information storage and retrieval system without written permission from

Wood-Mizer, LLC
8180 West 10th Street
Indianapolis, Indiana 46214

Table of Contents

Section-Page

SECTION 1	REPLACEMENT PARTS	1-1
1.1	How To Use The Parts List1-1 <i>To Order Parts</i>	
1.2	Sample Assembly1-1	
1.3	Torque Values1-2	
SECTION 2	BLADE GUIDE ROLLERS & ARM	2-1
2.1	Blade Guide Assembly, Idle Side.....2-1	
2.2	Blade Guide Assembly, Drive Side.....2-3	
2.3	Blade Guide Arm.....2-5	
SECTION 3	BLADE WHEELS & TENSIONER	3-1
3.1	Blade Drive Assembly.....3-1	
3.2	Idle Blade Wheel Assembly3-2	
3.3	Blade Tensioner Assembly.....3-3 <i>LT35HD Rev. A6.06+</i>	
3.4	Blade Tensioner Assembly.....3-4 <i>LT35HD Rev. A1.00 - A6.05</i>	
SECTION 4	SAW HEAD	4-1
4.1	Water Lube Assembly (2024-Present)4-1	
4.2	Water Lube Assembly (2019-2024)4-3	
4.3	Water Lube Assembly (2010-2019)4-4	
4.4	Saw Head Decals4-5	
4.5	Blade Housing Covers.....4-6	
4.6	Sawdust Chute4-7	
SECTION 5	ENGINE OPTIONS	5-1
	<i>LT35/LT35HD</i>	
SECTION 6	OPTIONS & ADDITIONAL INCLUDED EQUIPMENT	6-1
	<i>LT35HD</i>	
SECTION 7	CONTROL & BATTERY BOXES	7-1
7.1	Control Assembly.....7-1 <i>LT35 Rev. A5.00+</i> <i>LT35HD Rev. A5.00+</i>	
7.2	Control Assembly.....7-3 <i>LT35 Rev. A4.00 - A4.01</i> <i>LT35HD Rev. A4.00 - A4.01</i>	
7.3	Control Assembly.....7-6 <i>LT35 Rev. A1.00 - A3.00</i> <i>LT35HD Rev. A1.00 - A3.00</i>	
7.4	Drum Switches7-8	
7.5	Front Panel Assembly(2014-Present).....7-9	

Table of Contents

Section-Page

7.6	Front Panel Assembly (2013).....	7-10
7.7	Front Panel Assembly (2010-2013).....	7-11
7.8	Battery Box Assembly.....	7-12

SECTION 8 UP/DOWN SYSTEM

8-1

8.1	Saw Head Mount	8-1
8.2	Up/Down Assembly	8-3
	<i>LT35</i> <i>Rev. A5.00+</i>	
	<i>LT35HD</i> <i>Rev. A5.00+</i>	
8.3	Up/Down Assembly	8-5
	<i>LT35</i> <i>Rev. A3.00 - A4.01</i>	
	<i>LT35HD</i> <i>Rev. A3.00 - A4.01</i>	
8.4	Up/Down Assembly	8-8
	<i>LT35</i> <i>Rev. A2.00 - A2.01</i>	
	<i>LT35HD</i> <i>Rev. A2.00 - A2.01</i>	
8.5	Up/Down Assembly	8-10
	<i>LT35</i> <i>Rev. A1.00 - A1.02</i>	
	<i>LT35HD</i> <i>Rev. A1.00 - A1.03</i>	
8.6	Magnetic Position Sensor Assembly.....	8-13
	<i>LT35</i> <i>Rev. A5.00+</i>	
	<i>LT35HD</i> <i>Rev. A5.00+</i>	
8.7	Simple Set Sensor Assembly.....	8-15
	<i>LT35</i> <i>Rev. A3.00 - A4.01</i>	
	<i>LT35HD</i> <i>Rev. A3.00 - A4.01</i>	
8.8	Simple Set Sensor Assembly.....	8-16
	<i>LT35</i> <i>Rev. A2.00 - A2.01</i>	
	<i>LT35HD</i> <i>Rev. A2.00 - A2.01</i>	

SECTION 9 FEED SYSTEM & TRACK ROLLERS

9-1

9.1	Track Rollers And Wipers.....	9-1
9.2	Power Feed Assembly	9-3
	<i>LT35</i> <i>Rev. A4.00+</i>	
	<i>LT35HD</i> <i>Rev. A4.00+</i>	
9.3	Power Feed Assembly	9-5
	<i>LT35</i> <i>Rev. A1.00 - A3.00</i>	
	<i>LT35HD</i> <i>Rev. A1.00 - A3.00</i>	
9.4	Feed Chain/Stop	9-6

SECTION 10 BED FRAME ASSEMBLY

10-1

10.1	Bed Rail Assembly, Front And Rear.....	10-1
10.2	Bed Rail Assembly, Middle Front.....	10-2
10.3	Bed Rail Assembly, Middle Rear.....	10-3
10.4	Optional Legs Assembly ().....	10-4
10.5	Pivot Bed Rail Assembly.....	10-5
10.6	Log Side Support Assembly	10-6
10.7	Safety Chain Assembly	10-7
10.8	Saw Head Rest Pin Assembly	10-8
10.9	Bed Frame Decals.....	10-9

Table of Contents

Section-Page

10.10	Board Outfeed Table (Optional)	10-10
SECTION 11	BED HYDRAULIC SYSTEM	11-1
11.1	Hydraulic Hoses	11-1
11.2	Hydraulic Control Box	11-2
11.3	Hydraulic Power Supply Strip	11-5
11.4	Hydraulic Log Loader	11-8
11.5	Hydraulic Log Turner	11-10
11.6	Hydraulic Log Side Supports (Front/Rear)	11-11
11.7	Hydraulic Log Side Supports (Middle - Optional)	11-13
11.8	Hydraulic Log Clamp	11-14
11.9	Hydraulic Toe Board	11-16
SECTION 12	ACCESSORIES	12-17
	<i>LT35HD</i>	
SECTION 13	TRAILERS	13-1
	<i>LT35HD</i>	
SECTION 14	MISCELLANEOUS	14-1
14.1	Replacement Manuals	14-1
	INDEX	I

SECTION 1 REPLACEMENT PARTS

1.1 How To Use The Parts List

- Use the table of contents to locate the assembly that contains the part you need.
- Go to the appropriate section and locate the part in the illustration.
- Use the number pointing to the part to locate the correct part number and description in the table.
- Parts shown indented under another part are included with that part.

To Order Parts

- From the continental US, call **1-800-525-8100** to order parts. Have your customer number, vehicle identification number, and part numbers ready when you call.
- From other international locations, contact the Wood-Mizer distributor in your area for parts.

1.2 Sample Assembly

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	012345	SAMPLE ASSEMBLY, COMPLETE	INCLUDES ITEMS 1-6	1
1	F02222-22	Sample Part		1
2	F03333-33	Sample Part		2
	098765	Sample Subassembly	Includes items 3-6	1
3	S04444-44	Subassembly Sample Part		1
4	K55555	Subassembly Sample Part		1
	054321	Sample Sub-Subassembly	Includes items 5-6	2
5	022222	Sub-Subassembly Sample Part		1
6	F10234-56	Sub-Subassembly Sample Part		1


The Sample Assembly, Complete, part number 02345 (top level assembly) includes two parts (F0222-22 and F0333-33) and the 098765 subassembly.

Subassembly 098765 contains two parts(S04444-44 and K55555) and two copies of sub-subassembly 054321.

Each sub-subassembly 054321 contains two parts (022222 and F10234-56).

1.3 Torque Values

Grade		Units	SAE 5	SAE 8
Grade Mark				
Bolt Dia.	Threads. Per In.	Units	SAE 5	SAE 8
6	32	in-lbs (Nm)	20 (2.3)	-
8	32	in-lbs (Nm)	24 (2.7)	30 (3.4)
10	24	in-lbs (Nm)	35 (4.0)	45 (5.1)
10	32	in-lbs (Nm)	40 (4.5)	50 (5.7)
12	24	in-lbs (Nm)	50 (5.7)	65 (7.3)
1/4	20	in-lbs (Nm)	95 (10.7)	125 (14.1)
1/4	28	in-lbs (Nm)	95 (10.7)	150 (17.0)
5/16	18	ft-lbs (Nm)	17 (22.6)	23 (31.2)
5/16	24	ft-lbs (Nm)	20 (27.1)	25 (33.8)
3/8	16	ft-lbs (Nm)	30 (40.7)	40 (54.2)
3/8	24	ft-lbs (Nm)	35 (47.5)	45 (61.0)
7/16	14	ft-lbs (Nm)	50 (67.8)	65 (88.1)
7/16	20	ft-lbs (Nm)	55 (74.6)	70 (94.9)
1/2	13	ft-lbs (Nm)	75 (101.7)	100 (135.6)
1/2	20	ft-lbs (Nm)	85 (115.3)	110 (149.2)
9/16	12	ft-lbs (Nm)	105 (142.4)	135 (183.1)
9/16	18	ft-lbs (Nm)	115 (155.9)	150 (203.4)
5/8	11	ft-lbs (Nm)	150 (203.4)	195 (264.4)
5/8	18	ft-lbs (Nm)	160 (217.0)	210 (284.8)
3/4	10	ft-lbs (Nm)	170 (230.5)	220 (298.3)
3/4	16	ft-lbs (Nm)	175 (237.3)	225 (305.1)
7/8	9	ft-lbs (Nm)	302 (409.5)	473 (640.9)
7/8	14	ft-lbs (Nm)	300 (406.8)	400 (542.4)
1	8	ft-lbs (Nm)	466 (631.8)	714 (967.4)



Metric Bolt Head
Identification



**Metric
Grade 8.8**




**Metric
Grade 10.9**

COARSE THREAD					FINE THREAD					Wrench Size
Diameter & Thread Pitch	Metric 8.8		Metric 10.9		Diameter & Thread Pitch	Metric 8.8		Metric 10.9		
	N-m	lbs-ft	N-m	lbs-ft		N-m	lbs-ft	N-m	lbs-ft	
6 x 1.0	8	6	11	8						10 mm
8 x 1.25	20	15	27	20	8 x 1.0	21	16	29	22	13 mm
10 x 1.5	39	29	54	40	10 x 1.25	41	30	57	42	16 mm
12 x 1.75	68	50	94	70	12 x 1.25	75	55	103	76	18 mm
14 x 2.0	109	80	151	111	14 x 1.5	118	87	163	120	21 mm
16 x 2.0	169	125	234	173	16 x 1.5	181	133	250	184	24 mm
18 x 2.5	234	172	323	239	18 x 1.5	263	194	363	268	27 mm
20 x 2.5	330	244	457	337	20 x 1.5	367	270	507	374	30 mm
22 x 2.5	451	332	623	460	22 x 1.5	495	365	684	505	34 mm
24 x 3.0	571	421	790	583	24 x 2.0	623	459	861	635	36 mm
30 x 3.0	1175	867	1626	1199	30 x 2.0	1258	928	1740	1283	46 mm

SECTION 2 BLADE GUIDE ROLLERS & ARM


2.1 Blade Guide Assembly, Idle Side



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	A08197	BLADE GUIDE ASSEMBLY, COMPLETE IDLE SIDE		1
1	F05010-15	Nut, 1/2-20 Hex Nylon Lock		1
	A04925	Roller Assembly, Blade Guide (standard)		1
	K07079	Bearing Kit, Blade Guide Rebuild		1
2	P04252	Washer, 5/8" White Felt		1
3	F04254-1	Ring, 1 1/8" Interior Retaining		1
4	015975	Bearing, R8-2RS Blade Guide	Available in assemblies only.	2
5	P06455	Washer, 5/8" Gray Felt		1
	F05005-105	Screw, 1/4-28 x 1/4" Socket Head Cup Point Set Black Oxide		1
	057407-1507	Instruction Sheet, Blade Guide Rebuild		1
6	S04250	Roller, Flanged Blade Guide	Available in assemblies only.	1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	A04925-364	Instruction Sheet, Blade Guide Roller Replacement		1
7	S04253	Spacer, Blade Guide		2
8	036373	Bolt, Blade Guide Roller		1
9	W08495	Bracket, Blade Guide Idle Side With Water Tube		1
10	F05007-96	Screw, 3/8-24 X 1 1/4" Stainless Steel Socket Head Flat Point		2
11	F05010-22	Nut, 3/8-24 Jam		2
12	S08196	Shaft, Blade Guide Adjustment		1
13	F05007-95	SCREW, 3/8-24 X 3/4" STAINLESS STEEL SOCKET HEAD FLAT POINT		4
14	F05010-22	NUT, 3/8-24 JAM		4
15	W08159	TUBE, BLADE GUIDE MOUNT (<i>(See Section 2.3)</i>)		1
	016568	ROLLER ASSEMBLY, BLADE GUIDE RELUBE (OPTIONAL)		1
	057407	Bearing Kit, Relube Blade Guide Rebuild		1
16	P04252	Washer, 5/8" White Felt		1
17	F04254-1	Ring, 1 1/8" Interior Retaining		1
18	015975	Bearing, R8-2RS Blade Guide	Available in assemblies only. Bearing must be modified for use with relube roller assemblies. Remove one seal from each bearing, place open sides facing each other and place spacer 035411 between bearings.	2
19	P06455	Washer, 5/8" Gray Felt		1
	057407-1507	Instruction Sheet, Blade Guide Rebuild		1
20	035411	Spacer, Blade Guide Bearing		1
21	035426	Roller, Flanged Blade Guide Relube	Available in assemblies only.	1
	A04925-364	Instruction Sheet, Blade Guide Roller Replacement		1
22	S08192	BOLT, BLADE GUIDE ROLLER (RELUBE ONLY)		1
23	P05060	FITTING, 1/4-28 GREASE (RELUBE ONLY)		1


2.2 Blade Guide Assembly, Drive Side



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	A08191	BLADE GUIDE ASSEMBLY, COMPLETE DRIVE SIDE		1
1	F05010-15	Nut, 1/2-20 Hex Nylon Lock		1
	A04925	Roller Assembly, Blade Guide (standard)		1
	K07079	Bearing Kit, Blade Guide Rebuild		1
2	P04252	Washer, 5/8" White Felt		1
3	F04254-1	Ring, 1 1/8" Interior Retaining		1
4	015975	Bearing, R8-2RS Blade Guide	Available in assemblies only.	2
5	P06455	Washer, 5/8" Gray Felt		1
	F05005-105	Screw, 1/4-28 x 1/4" Socket Head Cup Point Set Black Oxide		1
	057407-1507	Instruction Sheet, Blade Guide Rebuild		1
6	S04250	Roller, Flanged Blade Guide	Available in assemblies only.	1
	A04925-364	Instruction Sheet, Blade Guide Roller Replacement		1
7	S04253	Spacer, Blade Guide		2
8	036373	Bolt, Blade Guide Roller		1
9	W08482	Bracket, Blade Guide Drive Side		1
10	F05007-96	Screw, 3/8-24 X 1 1/4" Stainless Steel Socket Head Flat Point		2
11	F05010-22	Nut, 3/8-24 Jam		2
12	S08196	Shaft, Blade Guide Adjustment		1
13	F05007-95	SCREW, 3/8-24 X 3/4" STAINLESS STEEL SOCKET HEAD FLAT POINT SET		3
14	F05010-22	NUT, 3/8-24 JAM		4
15	W08159	TUBE WELDMENT, BLADE GUIDE MOUNT (Part of saw frame weldment)		1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	016568	ROLLER ASSEMBLY, BLADE GUIDE RELUBE (OPTIONAL)		1
	057407	Bearing Kit, Relube Blade Guide Rebuild		1
16	P04252	Washer, 5/8" White Felt		1
17	F04254-1	Ring, 1 1/8" Interior Retaining		1
18	015975	Bearing, R8-2RS Blade Guide	Available in assemblies only. Bearing must be modified for use with relube roller assemblies. Remove one seal from each bearing, place open sides facing each other and place spacer 035411 between bearings.	2
19	P06455	Washer, 5/8" Gray Felt		1
20	035411	Spacer, Blade Guide Bearing		1
	057407-1507	Instruction Sheet, Blade Guide Rebuild		1
21	035426	Roller, Flanged Blade Guide Relube	Available in assemblies only.	1
	A04925-364	Instruction Sheet, Blade Guide Roller Replacement		1
22	S08192	BOLT, BLADE GUIDE ROLLER (RELUBE ONLY)		1
23	P05060	FITTING, 1/4-28 GREASE (RELUBE ONLY)		1

2.3 Blade Guide Arm




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	046966	ARM ASSEMBLY, LT15 BLADE GUIDE (2004)		1
1	046965	Arm Weldment, LT15 Blade Guide (2004)		1
2		Blade Guide Parts <i>((See Section 2.1))</i>		
3	014955	Guard, LT15 Blade Guide Arm		1
4	015849	Decal, LT15 Blade Guide Arm		1
5	F05005-1	Bolt, 1/4-20 x 3/4" Hex Head Full Thread		1
6	F05010-21	Nut, 1/4-20 Hex Lock		1
7	F05010-22	Nut, 3/8-24 Hex Jam		4
8	F05007-95	Screw, 3/8-24 x 3/4" Socket Head Flat Point Set		4
9	014973	Pad, Blade Guide Slide		3
10	076118	PLATE, LT15 WIDE BLADE GUIDE ARM ADJUSTMENT	Blade guide arm 076118 and link 076117 replaced blade guide arm 046827 and 046828 to improve operation (LT28 Rev. A6.11/LT35 Rev. A6.04/LT35HD Rev. A6.05). 049008 replaced 004742 5/8" ID Rubber Handle Grip (10/13). Previously, Link Handle 046828 and Grip 004742 replaced 048605 and 049008 originally supplied prior to Rev. A3.00. New handle provided clearance to allow operator access to logs or lumber on the sawmill bed.	1
11	076117 ¹	PLATE, LT15 WIDE BLADE GUIDE ARM LINK		1
12	F05007-87	BOLT, 3/8-16 X 1" HEX HEAD GRADE 5		2
13	F05011-3	WASHER, 3/8" SAE FLAT		3
14	F05010-10	NUT, 3/8-16 HEX NYLON LOCK		3
15	F05007-78	BOLT, 3/8-16 X 1 1/2" HEX HEAD GRADE 5		1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
16	049008	GRIP, 5/8" ID RUBBER HANDLE	Blade guide arm 076118 and link 076117 replaced blade guide arm 046827 and 046828 to improve operation (LT28 Rev. A6.11/LT35 Rev. A6.04/LT35HD Rev. A6.05). 049008 replaced 004742 5/8" ID Rubber Handle Grip (10/13). Previously, Link Handle 046828 and Grip 004742 replaced 048605 and 049008 originally supplied prior to Rev. A3.00. New handle provided clearance to allow operator access to logs or lumber on the sawmill bed.	1
17	F05007-95	SCREW, 3/8-24 X 3/4" STAINLESS SOCKET HEAD FLAT POINT SET		8
18	F05010-22	NUT, 3/8-24 HEX JAM		8
19	015899	BUSHING, BLADE GUIDE ARM		2
20	049141	BRACKET, SAW HEAD REST		1
21	F05007-73	BOLT, 3/8-16 X 3" HEX HEAD GRADE 5		2
22	F05010-10	NUT, 3/8-16 HEX NYLON LOCK		2
23	014882	BRACKET, BLADE GUIDE ARM GUIDE		1
24	F05006-124	BOLT, 5/16-18 X 1" FLAT HEAD SOCKET		1
25	F05010-6	NUT, 5/16-18 HEX LOCK		1


SECTION 3 BLADE WHEELS & TENSIONER

3.1 Blade Drive Assembly



REF	PART #	DESCRIPTION	COMMENTS	QTY.
		BLADE WHEEL BRAKE PARTS, G18 (See Engine Manual)		
		BLADE WHEEL BRAKE PARTS, D17 (See Engine Manual)		
		BLADE WHEEL BRAKE PARTS, D19 (See Engine Manual)		
		BLADE WHEEL BRAKE PARTS, G25 (See Engine Manual)		
	036657	WHEEL ASSEMBLY, DRIVE SIDE BLADE		1
1	047702	Wheel, Drive Side Blade		1
2	014811	Bearing, #6207 2RS		2
3	014730	Spacer, Drive Bearing		1
4	F04254-30	Ring, 3.121 IR Beveled Retaining		1
5	014728	WASHER, DRIVE WHEEL RETAINING		1
6	F05007-87	BOLT, 3/8-16 X 1" HEX HEAD		1
7	014729	SHAFT, LT15 DRIVE SIDE BLADE WHEEL		1
8	F05007-95	SCREW, 3/8-24 X 3/4" FLAT POINT SOCKET HEAD		3
9	F05010-22	NUT, 3/8-24 HEX JAM		4
10	(See Section 5)	BELT, DRIVE (SEE ENGINE MANUAL FOR PART #)		1
11	P04185	BELT, B57		1
12	F05011-4	WASHER, 3/8" SPLIT LOCK		1
13	F05007-96	SCREW, 3/8-24 X 1 1/4" FLAT POINT SOCKET HEAD		1

3.2 Idle Blade Wheel Assembly




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	A08218	WHEEL ASSEMBLY, IDLE SIDE BLADE		1
1	P08125	Wheel, Idle Side Blade	Available in assemblies only.	1
2	P08066	Bearing, Idle Side Blade Wheel #6305-AA, C3, ABEC-1, SRI-2 Grease		2
3	F04254-21	Ring, 2 7/16" Internal Retaining		1
4	S08220	WASHER, IDLE BLADE WHEEL RETAINER		1
5	F05006-102	BOLT, 5/16-18 X 3/4" HEX HEAD		1
6	P04185	BELT, BLADE WHEEL B57		1
7	F05009-3	BOLT, 5/8-11 X 4 1/2" HEX HEAD		1
8	014834	BEARING, 5/8" I.D. W/SNAP RING		2
9	F05010-34	NUT, 5/8-11 HEX NYLON LOCK		1
10	049349	IDLER WELDMENT, BLADE WHEEL		1
11	S12565	SHAFT, IDLE WHEEL		1
12	F05008-111	BOLT, 1/2-20 X 3 3/4" HEX HEAD FULL THREAD GRADE 2		1
13	S04253	SPACER, 1/2" I.D. FLANGED		2
14	F05010-16	NUT, 1/2-20 HEX JAM		4
15	F05011-9	WASHER, 1/2" SPLIT LOCK		1
16	F05008-127	BOLT, 1/2-20 X 1 3/4" HEX HEAD GRADE 5		2
17	F05011-13	WASHER, 5/16" SPLIT LOCK		1

3.3 Blade Tensioner Assembly

LT35HD

Rev. A6.06+




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	074801	TENSION ASSEMBLY, CAM ACTUATED BLADE(LT15/28/35, HR120/130)		1
1	049104	Cam, Tension		1
2	P05135	Bushing, 5/8" x 7/8" x 1/2" Bronze		2
3	103801	Handle, Blade Tensioner, LT15/28/35		1
4	P04211	Knob, 5/8-18 Ball		1
5	F05012-16	Pin, 3/16" x 1 1/4" Roll		2
6	128072	Block, Tensioner Bearing Mount		1
7	048219	Cam Follower, 3/8" x 1 3/8" x 13/16"		1
8	F05011-3	Washer, 3/8" SAE Flat		2
9	F05007-202	Bolt, 3/8 x 2 1/2" Socket Head Shoulder		1
10	F05010-58	Nut, 5/16-18 Hex Nylon Lock		1
11	038642	Shaft Weldment, Blade Tension		1
12	014925	Guide, Tension Handle		3
13	014828	Spring, Rubber Tensioner Blade		1
14	F05011-62	Washer, 3/4" SAE Flat		1
15	F05012-12	Pin, 1/4" x 1 1/4" Roll		1
16	F05007-157	Bolt, 3/8-16 x 2 1/2" Hex Head Full Thread		1
17	F05010-29	Nut, 3/8-16 Jam		1
18	F05011-4	Washer, 3/8" Split Lock		1
19	F05011-29	Washer, 3/4" USS Flat		1

3.4 Blade Tensioner Assembly

LT35HD

Rev. A1.00 - A6.05




SR0052

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	038643	TENSION ASSEMBLY, CAM ACTUATED BLADE		1
1	049104	Cam, Tension		1
2	P05135	Bushing, 5/8" x 7/8" x 1/2" Bronze		2
3	048804	Handle, Blade Tensioner		1
4	P04211	Knob, 5/8-18 Ball		1
5	F05012-16	Pin, 3/16" x 1 1/4" Roll		2
6	049321	Block, Tensioner Bearing Mount		1
7	048219	Cam Follower, 3/8" x 1 3/8" x 13/16"		1
8	F05011-3	Washer, 3/8" SAE Flat		2
9	F05007-202	Bolt, 3/8 x 2 1/2" Socket Head Shoulder		1
10	F05010-58	Nut, 5/16-18 Hex Nylon Lock		1
11	038642	Shaft Weldment, Blade Tension		1
12	014925	Guide, Tension Handle		3
13	014828	Spring, Rubber Tensioner Blade		1
14	F05011-62	Washer, 3/4" SAE Flat		1
15	F05012-12	Pin, 1/4" x 1 1/4" Roll		1
16	F05007-157	Bolt, 3/8-16 x 2 1/2" Hex Head Full Thread		1
17	F05010-29	Nut, 3/8-16 Jam		1
18	F05011-4	Washer, 3/8" Split Lock		1
19	F05011-29	Washer, 3/4" USS Flat		1

SECTION 4 SAW HEAD


4.1 Water Lube Assembly (2024-Present)



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	065063	Tray Assembly, LT35 Water Lube Bottle		1
	550787	Assembly, Water Bottle		1
1	550777	Fitting, G3/4" X 10mm Hose Barb		1
2	550778	Gasket, 1/2 (Batard)		1
3	550776	Fitting, Water Lube Shutoff Valve		1
4	530841	Shim, 21/37-1		1
5	550780	O-ring, 27x20x1.5		2
6	550785	Cap. Water Bottle		1
7	550779	Gland Nut, 1/2 Npt		1
8	513866	Bottle, Water		1
9	P11668	Strap, 20 Rubber W/hooks		2


REF	PART #	DESCRIPTION	COMMENTS	QTY.
10	R01885	Hose, Water Lube Stock		1
11	062530	Tray Weldment, Lt35 Water		1
12	012965	Strap, Rubber 9"		1
13	F05005-34	Bolt, 1/4-20 X 1 Carr		3
14	F05010-21	Nut, 1/4-20 Swaged		3
15	F05011-11	Washer, 1/4 SAE Flat		2
16	P07584	Clamp, 1/2emt Coated		1
17	F05011-14	Washer, 1/4 Split Lock		1
18	F05005-1	Bolt, 1/4-20x3/4 Ft Hhc		1
19	F05007-87	Bolt, 3/8-16x1 Gr5 Hh		3
20	F05011-4	Washer, 3/8 Split Lock		3
21	F05011-3	Washer, 3/8 Flat SAE		3

4.2 Water Lube Assembly (2019-2024)




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	065063	Tray Assembly, LT35 Water Lube Bottle		1
	550787	Assembly, Water Bottle		1
1	014113	Fitting, 5/8-3/8 Hose Barb		1
2	016086	Filter, Water Lube		1
3	133320	Valve, Water Bottle		1
4	036744	Cap, 63mm Water Bottle, Mod		1
5	014637	Bottle, 5Gal Water		1
6	R01885	HOSE, WATER LUBE STOCK		1
7	P11668	Strap, 20 Rubber W/Hooks		2
8	012965	Strap, Rubber 9"		1
9	F05005-34	Bolt, 1/4-20 X 1 Carr		3
10	F05010-21	Nut, 1/4-20 Swaged		3
11	F05007-87	Bolt, 3/8-16x1 Gr5 HH		3
12	F05011-4	Washer, 3/8 Split Lock		3
13	F05011-3	Washer, 3/8 Flat SAE		3
14	P07584	Clamp, 1/2EMT Coated		1
15	F05011-11	Washer, 1/4 SAE Flat		2
16	F05011-14	Washer, 1/4 Split Lock		1
17	F05005-1	Bolt, 1/4-20x3/4 FT HHC		1

4.3 Water Lube Assembly (2010-2019)




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	065063	TRAY ASSEMBLY, LT35 WATER LUBE BOTTLE		1
1	014642	Bottle, 5-Gallon Water Lube w/Cap		1
	061372	O-ring, Water Bottle Cap	If the water bottle cap keeps leaking, add this o-ring to the cap. Leave the existing o-ring installed.	1
	014636	Fitting, 3/4FPT x 3/4MPT	Deleted after 9/19/2022 per ECN 38718.	1
2	133320	Valve, 3/4 NPT Elbow 3/4 Male GHT Outlet	Replaced 014100 after 9/19/2022 per ECN 38718.	1
	014100	Fitting, Water Lube Shutoff Valve		1
3	014113	Fitting, 5/8" NPT to 3/8" Hose Barb		1
4	R01885	Tubing, Water Lube 3/8" I.D.		7 ft.
5	062530	Tray Weldment, LT35 Water		1
6	F05005-34	Bolt, 1/4-20 x 1" Carriage Head		3
7	F05010-21	Nut, 1/4-20 Hex Lock		3
8	P11668	Strap, 20" Rubber w/Hook		2
9	F05007-87	Screw, 3/8-16 x 1" Hex Head Grade 5		3
10	F05011-4	Washer, 3/8" Split Lock		3
11	F05011-3	Washer, 3/8" SAE Flat		3
12	012965	Strap, 9" Rubber With Hooks		1
13	F05011-11	Washer, 1/4" SAE Flat		1

4.4 Saw Head Decals




REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	014419	DECAL, HOT ENGINE WARNING		1
2	033254	DECAL, MOVING PARTS DANGER		2
3	S11752	DECAL, BLADE DANGER W/ARROW		1
4	015849	DECAL, BLADE GUIDE ARM STRIPE		1
5	079278	DECAL, WOOD-MIZER QUALITY & INFORMATION		1
6	P11754	DECAL, SAWDUST CHUTE WARNING		1
7	P11789	DECAL, BLADE TRACK INFO		1
8	S11773	DECAL, INCH SCALE		1
9	049367	DECAL, TENSIONER WARNING		1
10	049368	DECAL, BLADE TENSION INFO		1
11	003235	DECAL, WOOD-MIZER WEBSITE		1
12	016275	DECAL, MAGNETIC QUARTER SCALE		1
13	065008	DECAL, LT15/28/35 IDLE SIDE BLACK EURO STRIPE		1
14	065002	DECAL, LT10/15/28/35 WHITE WOOD-MIZER LOGO		1
15	065010	DECAL, LT28/35 DRIVE SIDE BLACK EURO STRIPE		1
16	065022	DECAL, LT35 WHITE EURO LOGO		1

4.5 Blade Housing Covers



REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	065067	COVER, LT35 DRIVE SIDE BLADE HOUSING (INCLUDES COVER DECALS - (See Section 4.4))		1
2	F05005-15	BOLT, 1/4-20 X 1/2" HEX HEAD		8
3	F05010-9	NUT, 1/4-20 KEPS		6
4	014829	LATCH, FLEXIBLE DRAW		2
5	F05004-3	SCREW, #10-24 X 3/8" CROSS SLOTTED ROUND HEAD		8
6	F05010-14	NUT, #10-24 SELF-LOCKING HEX		8
7	065068	COVER, LT35 IDLE SIDE BLADE HOUSING (INCLUDES COVER DECALS - (See Section 4.4))		1
8	015844	BLOCK, BLADE VIBRATION DAMPENING		1
9	F05015-33	BOLT, #10 X 3/4" SLOTTED HEX WASHER HEAD		2
10	074394	BRACKET WELDMENT, LT15 BELT ENHANCE	Used ONLY with engine models G25 & D17. EXCLUDED with engine model D24.	1
11	F05011-11	WASHER, 1/4" SAE FLAT		2
12	F05010-29	NUT, 3/8-16 JAM		1
13	F05007-18	SCREW, 3/8-16 X 1 1/4 SHOP SET		1
	038633	COVER ASSEMBLY, TOP ENGINE PULLEY		1
14	074574	Cover Weldment, LT15/28 Top Belt Cover		1
15	074546	Plate, Belt Guard Cover		1
16	F05005-134	Bolt, 1/4-20 x 3/4" Hex Head w/Conical Washer		4

4.6 Sawdust Chute



REF	PART #	DESCRIPTION	COMMENTS	QTY.
1-6	038747	CHUTE ASSEMBLY, LT28 SAWDUST		1
1	038746	Chute Wldmt, LT28 Sawdust		1
2	016727	Chute, Rubber Sawdust		1
3	F05015-7	Bolt, #10-24x1/2 Self Tap		2
4	F05006-5	Bolt, 5/16-18x3/4 HHC		2
5	F05011-13	Washer, 5/16 Split Lock		2
6	F05011-17	Washer, 5/16 SAE Flat		2
7	012965	STRAP, 9IN RUBBER WITH HOOKS		1
8	F05005-34	BOLT, 1/4-20X1 CARRIAGE		1
9	F05011-11	WASHER, 1/4 SAE FLAT		1
10	F05010-21	NUT, 1/4-20 SWAGED		1

SECTION 5 ENGINE OPTIONS

LT35/LT35HD

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1724	D17 KOHLER ENGINE OPTION (SEE ENGINE OPTION MANUAL)		D17
	M2208	D24 KOHLER ENGINE OPTION (SEE ENGINE OPTION MANUAL)		D24
	M1726	G25 KOHLER ENGINE OPTION (SEE ENGINE OPTION MANUAL)		G25

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1146	D51 CATERPILLAR ENGINE OPTION (SEE ENGINE OPTION MANUAL)		- M1140
	M1589	D55 YANMAR ENGINE OPTION (SEE ENGINE OPTION MANUAL)		- M159 1
	M1138	D62 CATERPILLAR ENGINE OPTION (SEE ENGINE OPTION MANUAL)		- M1140
	M1083	E25 LINCOLN ENGINE OPTION (SEE ENGINE OPTION MANUAL)		- M109 3 RC

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1589	D55 YANMAR ENGINE OPTION (SEE ENGINE OPTION MANUAL)		- M173 0

5 Engine Options

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1083	E25 LINCOLN ENGINE OPTION (SEE ENGINE OPTION MANUAL)		M178 2 EB
	M1778	E30 ENGINE OPTION (SEE ENGINE OPTION MANUAL)		- M178 3

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1589	D55 YANMAR ENGINE OPTION (SEE ENGINE OPTION MANUAL)		- M206 9

SECTION 6 OPTIONS & ADDITIONAL INCLUDED EQUIPMENT

LT35HD

REF	PART #	DESCRIPTION	COMMENTS	QTY.
AVAIL ABLE OPTI ONS				
	M530	BED EXTENSION (SEE MANUAL)		
	M2048	DEBARKER (076030) (SEE MANUAL)		
	M1524	FINE ADJUST OUTRIGGERS (2008) (SEE MANUAL)		

REF	PART #	DESCRIPTION	COMMENTS	QTY.
		INCLUDED EQUIPMENT		
	M1524	FINE ADJUST OUTRIGGERS (2008) (SEE MANUAL)		
		AVAILABLE OPTIONS		
	M530	BED EXTENSION (SEE MANUAL)		
	M1786	LASER SIGHT (SEE MANUAL)		

REF	PART #	DESCRIPTION	COMMENTS	QTY.
		INCLUDED EQUIPMENT		
	M1524	FINE ADJUST OUTRIGGERS (2008) (SEE MANUAL)		
		AVAILABLE OPTIONS		
	M530	BED EXTENSION (SEE MANUAL)		
	M1786	LASER SIGHT (SEE MANUAL)		

6

Options


REF	PART #	DESCRIPTION	COMMENTS	QTY.
		INCLUDED EQUIPMENT		
	M1523	ACCUSET 2 - REMOTE (SEE MANUAL)		
	M1106	MKII DEBARKER (AC) (SEE MANUAL)		
	M1060	MKII DEBARKER (DC) (SEE MANUAL)		
	M1524	FINE ADJUST OUTRIGGERS (2008) (SEE MANUAL)		
	M930	LUBEMIZER (SEE MANUAL)		
		AVAILABLE OPTIONS		
	M530	BED EXTENSION (SEE MANUAL)		
	M1081	LASER SIGHT (SEE MANUAL)		

SECTION 7 CONTROL & BATTERY BOXES

7.1 Control Assembly

LT35Rev. A5.00+

LT35HDRRev. A5.00+




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	073542	CONTROL ASSEMBLY, LT35D17/G25 POWER FEED		1
	073559	CONTROL ASSEMBLY, LT35D24 POWER FEED		1
1	071337	Plate, LT35 Control Box Cover		1
2	N/A	LT35 Operator Panel Parts ((See Section 7.5))		1
3	052365	Capacitor Assembly, PF Filter		1
4	024410	Clamp, Capacitor Metal 1-3/8 Cylindrical		1
5	F05010-153	Nut, #8-32 Square		2
6	F05015-24	Screw, #6-32 x 1/2" SI RH		1
7	F05010-59	Nut, #6-32 Keps		1
8	F05004-157	Screw, #8-32 x 3/8" Round Hd Mach Grade 5		2
9	F05011-84	Washer, #8 Split Lock		2
10	F05011-41	Washer, #8 SAE Flat		2
11	071335	Box Weldment, LT35 Control Bottom		1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
12	F05006-1	Bolt, 5/16-18 x 1" Hex Head		2
13	F05011-17	Washer, 5/16" SAE Flat		10
14	F05015-17	Bolt, #10-24 x1/2 Ph Pan Hd, Type 23		7
15	F05005-101	Bolt, 1/4-20 x 1" Hex Head Grade 5		2
16	F05011-11	Washer, 1/4" SAE Flat		8
17	076008	Bushing, 1/4" IDx1/2" OD Nylon		2
18	F05015-18	Bolt, #8-32 x 1/2" SI Hex Head		2
19	024396-1	Control Module, Power Feed SMT		1
	052294	Suppressor Assembly, 92+ Power Feed		1
20	F05010-41	Nut, #8-32 Keps		2
21	053373	H-Bridge Assembly, SimpleSet		1
22	F05011-14	Washer, 1/4" Split Lock		4
23	F05010-129	Nut, 1/4-20 Jam Heavy Duty		4
24	F05010-69	Nut, 1/4-20 Nylock		2
25	F05010-58	Nut, 5/16-18 Nylok Hex		2
26	024404	Block, Diode Heat Sink		1
	024403	Pad, Diode Block Insulating		1
	024409	Insulator, Nylon Screw #10 1/2in		4
27	F05010-14	Nut, #10-24 Keps		4
28	F05004-156	Bolt, #10-24 x1 Unslotted Hex Head Grade 2		4
29	F05011-18	Washer, #10 SAE Flat		4
30	053464	Breaker, 10A Manual Reset		2
31	F05010-9	Nut, 1/4-20 Keps		2
32	053784	Grommet, 25Pk 1-1/2" ID Rubber		1
33	F05005-15	Bolt, 1/4-20 x 1/2" Hex Head		2
34	N/A	Drum Switch Parts (See Section 7.4)		2
35	F05010-160	Nut, 10-24 Hex Nylock		4
36	F05011-18	Washer, #10 SAE Flat		4
37	F05005-31	Bolt, 1/4-20x1 1/2 HH FT		1
	024387	Module Assembly, Mosfet SMT 97+ P/F		1
38	F05005-1	Bolt, 1/4-20x3/4 FT HHC		2
39	F05010-129	Nut, 1/4-20 Jam Heavy Duty		2
40	F05011-11	Washer, 1/4" SAE Flat		6
41	F05011-69	Washer, 1/4" Int Star Heavy Duty		2
	073778	Harness Assembly, LT35 Simple Set Drum Switch		1
	073502	Harness Assembly, LT35 Upper (D17/G25 Only)	Upper harness modified to add ignition and start wires allowing to use key switch in control box to start engine (LT35/LT35HD Rev. A6.00).	1
	073558	Harness Assembly, LT35 Upper (D24 Only)		1
	053632-FR	Cable Assembly, Remote SimpleSet Sensor		1
	052363	Diode Assembly, 96+ PF Replacement		1
42	016402	DECAL, READ MANUAL WARNING		1
43	S11753	DECAL, EYE/EAR PROTECTION WARNING		1
44	S11762	DECAL, UP/DOWN CAUTION		1
45	015400	DECAL, FRONT OUTRIGGER WARNING		1
46	S12117	DECAL, 800 NUMBER		1

7.2 Control Assembly

LT35Rev. A4.00 - A4.01

LT35HRev. A4.00 - A4.01



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	071334	CONTROL ASSEMBLY, LT35D17 POWER FEED		1
1	071337	Plate, LT35 Control Box Cover		1
2	N/A	LT35 Operator Panel Parts (See Section 5.7)		1
3	052365	Capacitor Assembly, PF Filter		1
4	024410	Clamp, Capacitor Metal 1-3/8 Cylindrical		1
5	F05010-153	Nut, #8-32 Square		2
6	F05015-24	Screw, #6-32 x 1/2" SI RH		1
7	F05010-59	Nut, #6-32 Keps		1
8	F05004-157	Screw, #8-32 x 3/8" Round Hd Mach Grade 5		2
9	F05011-84	Washer, #8 Split Lock		2


REF	PART #	DESCRIPTION	COMMENTS	QTY.
10	F05011-41	Washer, #8 SAE Flat		2
11	071335	Box Weldment, LT35 Control Bottom		1
12	F05006-1	Bolt, 5/16-18 x 1" Hex Head		2
13	F05011-17	Washer, 5/16" SAE Flat		10
14	F05015-17	Bolt, #10-24 x1/2 Ph Pan Hd, Type 23		7
15	F05005-101	Bolt, 1/4-20 x 1" Hex Head Grade 5		2
16	F05011-11	Washer, 1/4" SAE Flat		8
17	076008	Bushing, 1/4" IDx1/2" OD Nylon		2
18	F05015-18	Bolt, #8-32 x 1/2" SI Hex Head		2
19	024396-1	Control Module, Power Feed SMT		1
20	F05010-41	Nut, #8-32 Keps		2
21	053373	H-Bridge Assembly, SimpleSet		1
22	F05011-14	Washer, 1/4" Split Lock		4
23	F05010-129	Nut, 1/4-20 Jam Heavy Duty		4
24	F05010-69	Nut, 1/4-20 Nylock		2
25	F05010-58	Nut, 5/16-18 Nylok Hex		2
26	024404	Block, Diode Heat Sink		1
	024403	Pad, Diode Block Insulating		1
	024409	Insulator, Nylon Screw #10 1/2in		4
27	F05010-14	Nut, #10-24 Keps		4
28	F05004-156	Bolt, #10-24 x1 Unslotted Hex Head Grade 2		4
29	F05011-18	Washer, #10 SAE Flat		4
30	053464	Breaker, 10A Manual Reset		2
31	F05010-9	Nut, 1/4-20 Keps		2
32	053784	Grommet, 25Pk 1-1/2" ID Rubber		1
33	F05005-15	Bolt, 1/4-20 x 1/2" Hex Head		2
34	N/A	Drum Switch Parts (See Section 7.4)		2
35	F05010-160	Nut, 10-24 Hex Nylock		4
36	F05011-18	Washer, #10 SAE Flat		4
37	F05005-31	Bolt, 1/4-20x1 1/2 HH FT		1
	024387	Module Assembly, Mosfet SMT 97+ P/F		1
38	F05005-1	Bolt, 1/4-20x3/4 FT HHC		2
39	F05010-129	Nut, 1/4-20 Jam Heavy Duty		2
40	F05011-11	Washer, 1/4" SAE Flat		6
41	F05011-69	Washer, 1/4" Int Star Heavy Duty		2
42	024502	PCB Assy, MOSFET Module SMT		1
43	024386	Block, Mosfet Module 6x SMT Clamp		1
44	024388	Pad, Mosfet Module 6x SMT		2
45	F05005-136	Screw, 1/4-20 x 1" Hex Flange Serrated SC		2
46	024385	Block, Mosfet Module 6x SMT		1
	073778	Harness Assembly, LT35 Simple Set Drum Switch		1
	073502	Harness Assembly, LT35 Upper	Upper harness modified to add ignition and start wires allowing to use key switch in control box to start engine (LT35/LT35HD Rev. A6.00).	1
	053632-FR	Cable Assembly, Remote SimpleSet Sensor		1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	052363	Diode Assembly, 96+ PF Replacement		1
47	016402	DECAL, READ MANUAL WARNING		1
48	S11753	DECAL, EYE/EAR PROTECTION WARNING		1
49	S11762	DECAL, UP/DOWN CAUTION		1
50	015400	DECAL, FRONT OUTRIGGER WARNING		1
51	S12117	DECAL, 800 NUMBER		1

7.3 Control Assembly

LT35Rev. A1.00 - A3.00

LT35HRev. A1.00 - A3.00




3H1087-1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	062521	CONTROL ASSEMBLY, LT35G25 POWER FEED		1
	053788	CONTROL ASSEMBLY, LT35D17 POWER FEED		1
1	062525	Plate, LT35 Control Box Cover		1
2	053786	LT35G25 Operator Panel Parts (See Section 5.8)		1
	053789	LT35D17 Operator Panel Parts (See Section 5.8)		1
3	053373	H-Bridge Assembly, SimpleSet		1
4	F05010-129	Nut, 1/4-20 Jam Heavy Duty		4
5	F05011-14	Washer, 1/4" Split Lock		4
6	F05015-17	Bolt, #10-24 x 1/2" Ph Pan Hd Type 23		7
7	053781	Breaker, 25A 12V Auto Reset		1
8	F05004-186	Screw, #10-24 x 1/2" Phil		3
9	065052	Control Box Weldment, LT35 Bottom		1
10	057829	Driver Assembly, LT35 PF		1
11	F05010-43	Nut, #4-40 Hex		4
12	F05011-21	Washer, #4 Split Lock		4
13	F05011-10	Washer, #4 Flat		4

REF	PART #	DESCRIPTION	COMMENTS	QTY.
14	F05010-58	Nut, 5/16-18 Nylok Hex		2
15	F05011-17	Washer, 5/16" SAE Flat		10
16	F05006-1	Bolt, 5/16-18 x 1" Hex Head		2
17	050436	Relay, 40A 12VDC Automotive		1
18	053699	Socket, 5 Pos Std Relay		1
19	053784	Grommet, 1-1/2" ID Rubber		1
20	F05010-160	Nut, 10-24 Hex Nylock		4
21	F05011-18	Washer, #10 SAE Flat		4
22	053772	PCB Assembly, LT35 Relay		1
23	P10489	Standoff, PC Board 3/8		4
24	053776	Fuseholder Assembly, LT35 2A		1
	053775	Harness Assembly, LT35 Main Relay		1
	053778	Harness Assembly, LT35 Simple Set		1
	053779	Harness Assembly, LT35G25 Upper		1
	053787	Harness Assembly, LT35D17 Upper		1
	053632	Cable Assembly, Remote SimpleSet Sensor		1
25	016402	DECAL, READ MANUAL WARNING		1
26	S11753	DECAL, EYE/EAR PROTECTION WARNING		1
27	S11762	DECAL, UP/DOWN CAUTION		1
28	015400	DECAL, FRONT OUTRIGGER WARNING		1
29	S12117	DECAL, 800 NUMBER		1

7.4 Drum Switches




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	E20440	SWITCH ASSEMBLY, UP/DOWN DRUM		1
1	E20440-B	Switch, S12 Bulk Drum	Available in assemblies only.	1
2	P12570	Spring, Drum Switch		1
3	P12500	Handle, Drum Switch Replacement		1
	E20439	SWITCH ASSEMBLY, POWER FEED DRUM		1
4	E20439-B	Switch, S11 Bulk Drum	Available in assemblies only.	1
5	P12570	Spring, Drum Switch		1
6	P12500	Handle, Drum Switch Replacement		1
7	F05011-41	WASHER, #8 SAE FLAT		6
8	A20463	CUP ASSEMBLY, DRUM SWITCH GREASE		1

7.5 Front Panel Assembly(2014-Present)

LT35 Rev. A5.00+

LT35HD Rev. A5.00+




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	073541	PANEL ASSEMBLY, LT35 OPERATOR		1
1	071339	Top Weldment, LT35 Control Box		1
2	053347	Membrane, SimpleSet Switch		1
3	071341	Decal LT35 Control Box		1
4	015401	Meter, Hour		1
5	F05015-28	Screw, #6-32 x 1/2" Plain PH T23		2
6	P03027	Switch, SPST On/Off 15A .25 Tabs Toggle		2
7	P02575	Boot, Toggle Switch		2
8	P06257	Knob, Speed Control		1
9	076050	Pot Assembly, w/Terminals		1
10	F05011-16	Washer, 5/16" Standard Flat		1
11	073540-FR	SimpleSet Controller, LT35 (Field Replacement)		1
12	053385	Standoff, 5/8" Threaded PCB		4
13	P04350	Switch, Key		1
14	021256	Breaker, 50A Manual Reset Panel Mount		2
15	021253	Boot, Circuit Breaker		2
	R02309	Foam, 3/16x1/2 Adhesive Back Rubber		2 ft.

7.6 Front Panel Assembly (2013)

LT35 Rev. A4.00-A4.01

LT35HD Rev. A4.00-A4.01




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	071338	PANEL ASSEMBLY, LT35 OPERATOR		1
1	071339	Top Weldment, LT35 Control Box		1
2	053347	Membrane, SimpleSet Switch		1
3	071341	Decal LT35 Control Box		1
4	015401	Meter, Hour		1
5	F05015-28	Screw, #6-32 x 1/2" Plain PH T23		2
6	P03027	Switch, SPST On/Off 15A .25 Tabs Toggle		2
7	P02575	Boot, Toggle Switch		2
8	P06257	Knob, Speed Control		1
9	076050	Pot Assembly, w/Terminals		1
10	F05011-16	Washer, 5/16" Standard Flat		1
11	053774-FR	SimpleSet Controller, (Field Replacement)		1
12	053385	Standoff, 5/8" Threaded PCB		4
13	P04350	Switch, Key		1
14	021256	Breaker, 50A Manual Reset Panel Mount		2
15	021253	Boot, Circuit Breaker		2
	R02309	Foam, 3/16x1/2 Adhesive Back Rubber		2 ft.

5.5 Front Panel Assembly (2010-2013)


LT35 Rev. A1.00 - A3.00

LT35HD Rev. A1.00 - A3.00



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	053786	PANEL ASSEMBLY, LT35G25 OPERATOR		
	053789	PANEL ASSEMBLY, LT35D17 OPERATOR		1
1	062522	Control Box Weldment, LT35 Top		1
2	P06257	Knob, Speed Control		1
3	F05011-16	Washer, 5/16" Standard Flat		1
4	A07793	Pot Assembly, Feed Rate Control Pre-92		1
5	015401	Meter, Hour Digital w/Gasket (G25 Only)		1
	065186	Plate, Hour Meter Cover (D17 Only)		1
6	053347	Membrane, SimpleSet Switch		1
7	062540	Decal, LT35 Operator		1
8	F05015-28	Screw, #6-32 x 1/2" Plain PH T23		10
9	53774-FR	SimpleSet Controller, (Field Replacement)		1
10	053385	Standoff, 5/8" Threaded PCB		4
11	053771	Switch Assembly, 4 Pos Joystick		2
12	P03027	Switch, SPST On/Off 15A .25 Tabs Toggle		1
13	P02575	Boot, Toggle Switch		1
	R02309	Foam, 3/16x1/2 Adhesive Back Rubber		2 ft.

7.8 Battery Box Assembly




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	062541	BATTERY BOX ASSEMBLY, LT35HD		1
1	P12315	Battery, Deka 12V, 24M77 800CCA 1000CA		1
2	F05092-16	Terminal, 5/16 1-2 Ga Ring NI Loose		2
3	F05011-33	Washer, 5/16" Star		2
4	062542	Box Weldment, LT35 Battery		1
5	062546	Cover, LT35 Battery		1
6	F05010-13	Nut, 1/4-20 Wing		2
7	F05011-11	Washer, 1/4" SAE Flat		6
8	F05006-2	Bolt, 5/16-18 X 1 1/2" Full Thread Hex Head Tap		2
9	F05005-15	Bolt, 1/4-20 x 1/2" Hex Head		6
10	F05011-14	Washer, 1/4" Split Lock		2
11	065040	Cover Weldment, Lt35 Fuse		1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
12	F05010-9	Nut, 1/4-20 Keps		4
13	052371	Fuseholder, Mega Fuse		2
14	053339	Fuse, 225A 32V Mega		2
15	052370-150	Fuse, 150A Mega		2
16	055323	Spacer, .39" x .625" x .39		2
17	F05011-17	Washer, 5/16" SAE Flat		4
18	F05010-20	Nut, 5/16-18 Keps		4
19	F05007-87	Bolt, 3/8-16 x 1" Hex Head Grade 5		2
20	F05011-3	Washer, 3/8" Flat Sae		2
21	F05010-10	Nut, 3/8-16 Hex Nyloc		2
22	P04137	Grommet, 5/8" Wire		2
23	P11764	Grommet, 5/8" ID Rubber		2
24	F05005-123	Bolt, 1/4-20 x 3/4" Hex Head Grade 5		2
25	F05010-69	Nut, 1/4-20 Nylock		2
26	065082	Plate, Battery Hold Down		1
	065103	Wire Assembly, LT35 Fuse Jumper		1
27	P12960	Decal, Hydraulic Contact Caution		1
28	P10364	Decal, 12V Warning		1
29	014774	Decal, Battery Box Lid Caution		1
		Hydraulic Positive Contact Parts ((See Section 11.3))		

SECTION 8 UP/DOWN SYSTEM

8.1 Saw Head Mount



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	062519 ¹	BOX ASSEMBLY, LT35 MAST		1
1	048562	Adjustment Weldment, Head LT28		1
2	F05010-127	Nut, 1/2-13 Half Nylon Lock		2
3	F05008-132	Bolt, 1/2-13x2 Carriage		2
4	P08066	Bearing, .9843" x 2.4409" x .6693"		4
5	F04254-26	Ring, 25mm 5100-98 OR		1
6	003327	Plate, Clutch Handle		1
7	P04211	Knob, 5/8-18 Ball		1
8	F05010-8	Nut, 1/2-13 Nylon Hex Lock		1
9	P08060	Bearing, SF1260-6 Bronze		1
10	014972	Washer, 33/64 x 1 3/4 x 1/32 Nylon		1
11	P09814	Rod, 5/16-24 Male End		1
12	P09813	Rod, 5/16-24 Female End		1
13	F05008-96	Bolt, 5/16-18 x 1 1/2" Hex Head		2
14	F05010-58	Nut, 5/16-18 Nylon Lock		2
15	F05007-123	Bolt, 3/8-16 x 1 1/4" Hex Head Grade 5		1
16	F05011-3	Washer, 3/8" SAE Flat	Reduced QTY 8 to QTY 7 after 10/7/2014 per ECN 20168.	7
17	F05010-10	Nut, 3/8-16 Hex Nylon Lock		5
18	048559	Shaft, Bearing Mount		3
19	P06030-1	Bearing, 5/8" x 1.7548" x .4724"		3
20	F04254-2	Ring, 5/8" OR 5100-62		6

REF	PART #	DESCRIPTION	COMMENTS	QTY.
21	F05011-4	Washer, 3/8" Split Lock	Reduced QTY 7 to QTY 6 after 10/7/2014 per ECN 20168.	6
22	F05007-87	Bolt, 3/8-16 x 1" Hex Head Grade 5	Reduced QTY 6 to QTY 5 after 10/7/2014 per ECN 20168.	5
23	F05007-205	Bolt, 3/8-16 X 6 1/2" Hex Head Grade 5		3
24	048560	Shaft, Fixed Mount		1
25	F05007-78	Bolt, 3/8-16 x 1 1/2" Hex Head Grade 5		2
26	F05007-88	Screw, 3/8-16x1 Scket Head Set Brass Tip		2
27	F05010-29	Nut, 3/8-16 Jam		2
28	F05007-17	Bolt, 3/8-16 x 1 1/2" Hex Head Full Thread		2
29	049133	Plate, Scale Mount		1
30	F05006-102	Bolt, 5/16-18 x 3/4" Hex Head		2
31	F05011-13	Washer, 5/16" Split Lock		2
32	F05011-17	Washer, 5/16" SAE Flat		2
33	062516	Box Weldment, LT35 Mast		1
34	F05007-19	Bolt, 3/8-16 x 1 3/4" Hex Head Full Thread		1
35	F05007-64	Screw, 3/8-16 x 1" Zinc & Bake FSHC	Added after 10/7/2014 per ECN 20168.	1

¹ Modified to make access to blade guide jam nut easier for adjustments (LT35 Rev. A6.02/LT35HD Rev. A6.02).


8.2 Up/Down Assembly

LT35

Rev. A5.00+

LT35HD

Rev. A5.00+



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	062515	MAST ASSEMBLY, LT35		1
	066799	Up/Down Assembly, LT35		1
1	006747	Motor, 1/2HP 12VDC		1
	061794	Brush Kit, 12V Motor		1
2	074166	Gear Box, Up/Down Grove		1
	076149	Gear Box, Up/Down Grove		1
	L04869-3	Gear Oil, ISO 460 Synthetic Bulk		1
3	S31027	Key, 3/16" x 1" Square		1
4	008721	Bracket, Up/Down Motor 3/4HP		1
5	F05007-7	Bolt, 3/8-16 x 1" Hex Head Cap		4
6	F05011-4	Washer, 3/8" Split Lock		8
7	F05011-3	Washer, 3/8" SAE Flat		4
8	F05007-118	Bolt, 3/8-16 x 3/4" Hex Head Grade 5		1
9	066781	Sheave, 5.45 OD 3/4 Bore 4L		1
10	S09579	Sheave, 1 3/4" Feed Motor		1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
11	F05007-12	Screw, 3/8-16 x 1/2" SH Cup Pt Set		2
12	038459	Belt, 4L245 Notched		1
13	F05005-1	Bolt, 1/4-20 x 3/4" Full Thread HHCap		1
14		Magnetic Position Sensor Parts	(See Section 8.6)	
15	F05007-123	Bolt, 3/8-16 x 1 1/4" Hex Head Grade 5		3
16	F05011-14	Washer, 1/4" Split Lock		4
17	F05011-11	Washer, 1/4" SAE Flat		4
18	F05005-38	Screw, 1/4-20 x 1" Hex Head Cap		3
19	066797	Plate, LT35 Up/Down Mounting		1
20	066789	Plate, Up/Down Sprocket Support		1
21	066795	Plate, Up/Down Bearing Mount		1
22	F05007-64	Screw, 3/8-16 x 1" Zinc & Bake FSHC		5
23	F05006-22	Bolt, 5/16-18 x 1" FHS		2
24	066794	Sprocket, D40B14 x 1-1/8" Keyed Bore		1
25	F05005-131	Screw, 1/4-20 x 1/4" SH Cup Pt Set		1
	074932	Sprocket Assembly, D40B14 Idler	Replaces 066792 D40B14 Idler Sprocket Assembly equipped with P04156 Bearing, 066796 Sprocket and F04254-11 1 3/8" IR 3000x137 Retaining Ring (4/16).	1
26	074931	Bearing, 6202-16mm-2RLD		2
27	074930	Sprocket, D40B14x1.376 Bore		1
28	066798	Bearing, 1-1/8 Bore R18-2Rs		1
29	066783	Pin Weldment, 5/8" x 2 3/4"		1
30	062526	Mount Weldment, LT35 Upper Chain	062526 Mount Weldment replaced 065723 Mount Assembly including 062526 Mount Weldment, S12392 1/4-20 Weld Nut and 065717 Rubber Bumper (LT35 Rev. A6.06/LT35HD Rev. A6.07).	1
	062527	Tensioner Assembly, LT35 Up/Down Chain		1
31	062528	Tensioner Weldment, LT35 Up/Down Chain		1
32	F05011-2	Washer, 1/2" SAE Flat		2
33	016515	Spacer, Up/Down Chain Tensioner		1
34	016516	Spring, 1" OD x 1" Long x .125 Wire Comp		1
35	F05010-8	Nut, 1/2-13 Hex Nylon Lock		1
	074022	Chain, Double #40x 117 Pitches(58-1/2")		1
	017724	Link, #40 Double, Connecting		2
36	076152	GUARD WELDMENT, LT35 UP/DOWN		1
37	076153	COVER WELDMENT, LT35 UP/DOWN GUARD		1
38	F05005-134	BOLT, 1/4-20 X 1/2" HEX HEAD		7
39	F05010-9	NUT, 1/4-20 KEPS		1
40	071229	CLAMP, 3/8" EMT COATED		1
41	S04124	KEY, 1/4" X 1 11/16"		1


8.3 Up/Down Assembly

LT35

Rev. A3.00 - A4.01

LT35HD

Rev. A3.00 - A4.01



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	062515	MAST ASSEMBLY, LT35		1
	066799	Up/Down Assembly, LT35		1
1	006747	Motor, 1/2HP 12VDC		1
	061794	Brush Kit, 12V Motor		1
2	065732	Boot, LT35 Debarker Motor Rubber		1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
3	074124	Gear Box, Up/Down Grove GR8245953.00	Replaces 014074 Gear Box Reducer to help eliminate head drift (LT35 Rev. A4.01LT35HD Rev. A4.01).	1
	L04869-3	Gear Oil, ISO 460 Synthetic Bulk		1
4	008721	Bracket, Up/Down Motor 3/4HP		1
5	F05007-7	Bolt, 3/8-16 x 1" Hex Head Cap		4
6	F05011-4	Washer, 3/8" Split Lock		8
7	S31027	Key, 3/16" x 1" Square		1
8	074170	Mount, LT35 Up/Down Guard	074170 replaces 074014 LT35 Up/Down Guard Mount and 074173 replaces 074011 LT35 Up/Down Weldment Guard to improve fit and provide more clearance between compo- nents (LT35 Rev. A4.01LT35HD Rev. A4.01).	1
9	066781	Sheave, 5.45 OD 3/4 Bore 4L		1
10	S09579	Sheave, 1 3/4" Feed Motor		1
11	F05007-12	Screw, 3/8-16 x 1/2" SH Cup Pt Set		1
12	038459	Belt, 4L245 Notched		1
13	074173 ²	Guard, LT35 Up/Down Weldment		1
14		Position Sensor Parts ((See Section 8.7))		
15	F05005-15	Bolt, 1/4-20 x 1/2" Hex Head		3
16	F05011-14	Washer, 1/4" Split Lock		7
17	F05011-11	Washer, 1/4" SAE Flat		7
18	F05005-38	Screw, 1/4-20 x 1" Hex Head Cap		3
19	066797	Plate, LT35 Up/Down Mounting		1
20	066789	Plate, Up/Down Sprocket Support		1
21	066795	Plate, Up/Down Bearing Mount		1
22	F05007-64	Screw, 3/8-16 x 1" Zinc & Bake FSHC		5
23	F05006-22	Bolt, 5/16-18 x 1" FHS		2
24	066794	Sprocket, D40B14 x 1-1/8" Keyed Bore		1
25	F05005-131	Screw, 1/4-20 x 1/4" SH Cup Pt Set		1
	066792	Sprocket Assembly, D40B14 Idler		1
26	P04156	Bearing, R-10		2
27	066796	Sprocket, D40B14 Modified		1
28	F04254-11	Ring, 1 3/8" IR 3000x137 Retaining		1
29	066798	Bearing, 1-1/8 Bore R18-2Rs		1
30	066783	Pin Weldment, 5/8" x 2 3/4"		1
31	F05007-118	Bolt, 3/8-16 x 3/4" Hex Head Grade 5		1
32	F05005-1	Bolt, 1/4-20 x 3/4" Full Thread Hex Head Cap		1
33	F05007-123	Bolt, 3/8-16 x 1 1/4" Hex Head Grade 5		3
	065723	Mount Assembly, LT35 Upper Chain		1
34	062526	Weldment, LT35 Upper Chain Mount		1
35	S12392	Nut, 1/4-20 Weld Plated		1
36	065717	Bumper, 1" x 3/4" Hard Silicone Rubber		1
	062527	Tensioner Assembly, LT35 Up/Down Chain		1
37	062528	Tensioner Weldment, LT35 Up/Down Chain		1
38	F05011-2	Washer, 1/2" SAE Flat		2

REF	PART #	DESCRIPTION	COMMENTS	QTY.
39	016515	Spacer, Up/Down Chain Tensioner		1
40	016516	Spring, 1" OD x 1" Long x .125 Wire Comp		1
41	F05010-8	Nut, 1/2-13 Hex Nylon Lock		1
	074022	Chain, Double #40x 117 Pitches(58-1/2")		1
	017724	Link, #40 Double, Connecting		2
42	074013	GUARD, LT35 UP/DOWN SPROCKET		1
43	F05005-15	BOLT, 1/4-20 X 1/2" HEX HEAD		2
44	F05011-14	WASHER, 1/4" SPLIT LOCK		2
45	F05011-11	WASHER, 1/4" FLAT		2


8.4 Up/Down Assembly

LT35

Rev. A2.00 - A2.01

LT35HD

Rev. A2.00 - A2.01



3H1126

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	062515	MAST ASSEMBLY, LT35		1
	071100	Up/Down Assembly, LT35 w/Clutch		1
	065849	Gearmotor Assembly, 6RPM w/Brake		1
1	071096	Motor, 6RPM w/Brake Gear	Available in assemblies only.	1
	065908	Brake Assembly, LT35 Up/Down Replacement		1
	069519	Brake, Klauber Gearmo- tor #K01134D300	Available in assemblies only.	1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	F05703-7	Terminal, #10 18-22AWG Ring		2
2	F05092-9	Terminal, #10 14-16Ga Ring NI Loose		2
3	F05703-7	Terminal, #10 18-22AWG Ring NI Loose		2
	R02374	Conduit, 1/2" Expandable Black		1
4	049018	Bushing, Flange 1/4" ID x 1/4" Lg		1
5		Position Sensor Parts (See Section 8.8)		
6	024155	Clamp, 1/4" Wire 13/32" Mtg Hole		1
7	F05011-13	Washer, 5/16" Split Lock		4
8	F05006-102	Bolt, 5/16-18 x 3/4" Hex Head Grade 5		1
9	F05009-10	Bolt, 5/8-11 x 4 1/2" Hex Head Grade 5		1
10	071102	Spacer, 5/8" x 3/4" x 1"		2
11	071101	Plate, LT35 Up/Down Gearmotor Mount		1
12	F05006-79	Bolt, 5/16-18 x 2" Hex Head Grade 5		2
13	F05011-11	Washer, 1/4" SAE Flat		2
14	F05005-15	Bolt, 1/4-20 x 1/2" Hex Head		2
15	P32044	Bearing, R12-2NSL		2
16	F05006-15	Bolt, 5/16-18 x 1/2" Hex Head Grade 5		1
17	071097	Nut, LT35 Up/Down Brake Adjustment		2
18	F05011-135	Washer, 1 1/4" x 2 1/2" x .120 Belleville		2
19	071095	Plate, LT35 Up/Down Brake Backer		3
20	071093	Pad, LT35 Up/Down Friction		4
21	071091	Sprocket, 40A19 x 1.253		2
22	065848	Key, 3/16" Sq x 2"		1
23	071092	Shaft, LT35 Up/Down Sprocket Mount		1
24	F05005-197	Screw, 1/4-20 x 1/8" SH BO Hollow Lock Set		1
25	071098	Plate, LT35 Up/Down Bearing Mount		1
	065108	Sprocket Assembly, D40B17 Idler		1
26	F04254-11	Ring, 1 3/8" IR 3000x137 Retaining		1
27	P04156	Bearing, R-10		2
28	065107	Sprocket, D40B17 Modified		1
29	F05010-96	Nut, 5/8-11 Jam Nylon Lock		1
30	F05007-87	Bolt, 3/8-16 x 1" Hex Head Grade 5		3
31	F05011-4	Washer, 3/8" Split Lock		3
32	F05011-3	Washer, 3/8" Flat SAE		3
33	071088	Plate, LT35 Up/Down w/Clutch Mount		1
34	F05006-19	Bolt, 5/16-18 x 1" Socket Head Cap B/O		4
	065723	Mount Assembly, LT35 Upper Chain		1
35	062526	Weldment, LT35 Upper Chain Mount		1
36	S12392	Nut, 1/4-20 Weld Plated		1
37	065717	Bumper, 1" x 3/4" Hard Silicone Rubber		1
	065850	Chain, Double #40 x 121 Pitches (60-1/2")		1
	017724	Link, #40 Double Connecting		2
	062527	Tensioner Assembly, LT35 Up/Down Chain		1
38	062528	Tensioner Weldment, LT35 Up/Down Chain		1
39	F05011-2	Washer, 1/2" SAE Flat		2

REF	PART #	DESCRIPTION	COMMENTS	QTY.
40	016515	Spacer, Up/Down Chain Tensioner		1
41	016516	Spring, 1" OD x 1" Long x .125 Wire Comp		1
42	F05010-3	Nut, 1/2-13 Swaged Hex		1
43	062532	WELDMENT, LT35 DRIVE SIDE UP/DOWN COVER		1
44	F05005-15	BOLT, 1/4-20 X 1/2" HEX HEAD		2
45	F05011-14	WASHER, 1/4" SPLIT LOCK		2
46	014829	LATCH, FLEXIBLE DRAW		1
47	F05004-3	SCREW, #10-24 X 3/8" PHILLIPS PH MACHINE		4
48	F05010-14	NUT, #10-24 KEPS		4


8.5 Up/Down Assembly

LT35

Rev. A1.00 - A1.02

LT35HD

Rev. A1.00 - A1.03



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	062515	MAST ASSEMBLY, LT35		1
	059639	Up/Down Assembly, LT35		1
	065746	Gearmotor Assembly, LT35 Up/Down	065746 Up/Down Gearmotor Assembly modified to include "tougher" gears and 065723 Upper Chain Mount Assembly replaced 062526 Upper Chain Mount Weldment to improve up/down operation (LT35 Rev. A1.01 and LT35HD Rev. A1.02). Use LT35 Up/Down Upgrade Kit 074029 for service. LT35 Up/Down Safety Campaign Kit 065728 used to upgrade saw-mills prior to LT35 Rev. A1.02 and LT35HD Rev. A1.03 is no longer available.	1
1	062510	Motor, Gear 250:1 w/Brake	Available in assemblies only.	1
	065908	Brake Assembly, LT35 Up/Down Replacement		1
	069519	Brake, Klauber Gearmotor #K01134D300	Available in assemblies only.	1
	F05703-7	Terminal, #10 18-22AWG Ring		2
	F05708-15	Terminal, 1/4" 10-12Ga Quick Male FI		2
	R02374	Conduit, 1/2" Expandable Black		1
2	049018	Bushing, Flange 1/4" ID x 1/4" Lg		1
3	065061	Sensor Assembly, LT35 Position		1
4	F05011-13	Washer, 5/16" Split Lock		4
5	F05006-5	Bolt, 5/16-18 x 3/4" Hex Head		2
6	F05009-118	Bolt, 5/8-11 x 3 3/4" Hex Head Grade 5		1
7	065062	Spacer, 5/8" x 1" x 1"		2
8	062481	Plate, Bearing Mount		2
9	F05006-80	Bolt, 5/16-18 x 2 1/2" Hex Head Grade 5		2
10	F05011-11	Washer, 1/4" SAE Flat		2
11	F05005-15	Bolt, 1/4-20 x 1/2" Hex Head		2
12	P32044	Bearing, R12-2NSL		2
13	016108	Key, 3/16" SQ. x 1 3/8"		1
14	062549	Sprocket, D40B12 x 3/4"		1
	065108	Sprocket Assembly, D40B17 Idler		1
15	F04254-11	Ring, 1 3/8" IR 3000x137 Retaining		1
16	P04156	Bearing, R-10		2
17	065107	Sprocket, D40B17 Modified		1
18	F05010-96	Nut, 5/8-11 Jam Nylon Lock		1
19	F05007-87	Bolt, 3/8-16 x 1" Hex Head Grade 5		3
20	F05011-4	Washer, 3/8" Split Lock		3
21	F05011-3	Washer, 3/8" Flat SAE		3
22	062482	Plate, LT35 Up/Down Mount		1
23	F05006-19	Bolt, 5/16-18 x 1" Socket Head Cap B/O		4
	065723 ¹	Mount Assembly, LT35 Upper Chain		1
24	062526	Weldment, LT35 Upper Chain Mount		1
25	S12392	Nut, 1/4-20 Weld Plated		1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
26	065717	Bumper, 1" x 3/4" Hard Silicone Rubber		1
	065059	Chain, Double #40 x 111 Pitches (55-1/2")		1
	017724	Link, #40 Double, Connecting		2
	062527	Tensioner Assembly, LT35 Up/Down Chain		1
27	062528	Tensioner Weldment, LT35 Up/Down Chain		1
28	F05011-2	Washer, 1/2" SAE Flat		2
29	016515	Spacer, Up/Down Chain Tensioner		1
30	016516	Spring, 1" OD x 1" Long x .125 Wire Comp		1
31	F05010-3	Nut, 1/2-13 Swaged Hex		1
32	062532	WELDMENT, LT35 DRIVE SIDE UP/DOWN COVER		1
33	F05005-15	BOLT, 1/4-20 X 1/2" HEX HEAD		2
34	F05011-14	WASHER, 1/4" SPLIT LOCK		2
35	014829	LATCH, FLEXIBLE DRAW		1
36	F05004-3	SCREW, #10-24 X 3/8" PHILLIPS PH MACHINE		4
37	F05010-14	NUT, #10-24 KEPS		4


8.6 Magnetic Position Sensor Assembly

LT35

Rev. A5.00+

LT35HD

Rev. A5.00+



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	053369	SENSOR ASSEMBLY, MAGNETIC POSITION		1
1	006864	Gasket, Encoder		1
2	053376	PCB Assembly, Encoder Sensor	Available in assemblies only.	1
3	053387	Sensor Kit, Magnetic Encoder		1
4	053399	Enclosure, Position Sensor		1
5	053400	Lens, LED T1 Clear		1
6	057853	Plate, SimpleSet Encoder Slide		1
7	061518	Plate, SimpleSet Encoder Mount		1
8	F05004-18	Screw, 10-24 x 5/8" Unsl Indent Hex Head Machine		2
9	F05004-49	Screw, #4-40 x 5/8" SI Rnd Head Machine		2
10	F05010-160	Nut, 10-24 Hex Nylock		2

REF	PART #	DESCRIPTION	COMMENTS	QTY.
11	F05010-43	Nut, #4-40 Hex		2
12	F05011-18	Washer, #10 SAE Flat		4
13	F05011-21	Washer, #4 Split Lock		2
14	F05015-18	Bolt, #8-32 x 1/2" SI Hex Head S		2
15	057852	Extension, SimpleSet Gearbox Shaft		1
16	F05005-131	Screw, 1/4-20 x 1/4" SH Cup Pt Set		1
17	049018	Bushing, Flange 1/4" ID x 1/4" Lg		1
18	F05006-5	Bolt, 5/16-18 x 3/4" Hex Head Cap		4
19	F05011-13	Washer, 5/16" Split Lock		4
20	F05011-17	Washer, 5/16" SAE Flat		4
21	057872	Plate, SimpleSet Mount		1
22	074269	Decal, Encoder Bolt Warning		1
23	065890	Magnet Assembly, Simple Set Encoder w/Hub		1


8.7 Simple Set Sensor Assembly

LT35

Rev. A3.00 - A4.01

LT35HD

Rev. A3.00 - A4.01



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	074021	SENSOR ASSEMBLY, LT35 SIMPLE SET MAGNETIC POSITION		1
1	006864	Gasket, Encoder		1
2	053376	PCB Assembly, Encoder Sensor	Available in assemblies only.	1
3	053387	Sensor Kit, Magnetic Encoder		1
4	053399	Enclosure, Position Sensor		1
5	053400	Lens, LED T1 Clear		1
6	059691	Plate, LT35 Simple Set Encoder		1
7	074012	Plate, LT35 Encoder Mount		1
8	F05004-18	Screw, 10-24 x 5/8" Unsl Indent HH Machine		2

REF	PART #	DESCRIPTION	COMMENTS	QTY.
9	F05004-49	Screw, #4-40 x 5/8" SI Rnd Head Machine		2
10	F05010-160	Nut, 10-24 Hex Nylock		2
11	F05010-43	Nut, #4-40 Hex		2
12	F05011-18	Washer, #10 SAE Flat		4
13	F05011-21	Washer, #4 Split Lock		2
14	F05015-18	Bolt, #8-32 x 1/2" SI HH S		2
15	057852	Extension, SimpleSet Gearbox Shaft		1
16	F05005-131	Screw, 1/4-20 x 1/4" SH Cup Pt Set		1
17	049018	Bushing, Flange 1/4" ID x 1/4" Lg		1
18	F05006-5	Bolt, 5/16-18 x 3/4" Hex Head Cap		4
19	F05011-13	Washer, 5/16" Split Lock		4
20	F05011-17	Washer, 5/16" SAE Flat		4
21	057872	Plate, SimpleSet Mount		1
22	F05011-11	Washer, 1/4" SAE Flat		1
23	074269	Decal, Encoder Bolt Warning		1
24	065890	Magnet Assembly, Simple Set Encoder w/Hub		1


8.8 Simple Set Sensor Assembly

LT35

Rev. A2.00 - A2.01

LT35HD

Rev. A2.00 - A2.01




Up/Down System *Simple Set Sensor Assembly*

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	071103	SENSOR ASSEMBLY, LT35 SIMPLE SET		1
1	006864	Gasket, Encoder		1
2	053376	PCB Assembly, Encoder Sensor	Available in assemblies only.	1
3	053387	Sensor Kit, Magnetic Encoder		1
4	053399	Enclosure, Position Sensor		1
5	053400	Lens, LED T1 Clear		1
6	059691	Plate, LT35 Simple Set Encoder		1
7	071099	Plate, LT35 Simple Set Encoder Mount		1
8	F05004-18	Screw, 10-24 x 5/8" Unsl Indent HH Machine		2
9	F05004-49	Screw, #4-40 x 5/8" SI Rnd Head Machine		2
10	F05010-160	Nut, 10-24 Hex Nylock		2
11	F05010-43	Nut, #4-40 Hex		2
12	F05011-18	Washer, #10 SAE Flat		2
13	F05011-21	Washer, #4 Split Lock		2
14	F05015-18	Bolt, #8-32 x 1/2" SI HH S		2
15	065890	Magnet Assembly, Simple Set Encoder w/Hub		1

SECTION 9 FEED SYSTEM & TRACK ROLLERS

9.1 Track Rollers And Wipers



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	062514	UPRIGHT ASSEMBLY, LT35		1
1	023857	Bearing, MG305DDA		2
2	F04254-15	Ring, 1" Outer Retaining		2
3	012797	Bearing, Cam Follower 1 1/2" (McGill)		2
4	062537	Plate, LT35 Pointer Mount		1
5	049342	Cover Weldment, Rear Bearing		1
6	049341	Cover Weldment, Front Bearing		1
7	M04113	Wiper, Top Rail		2
8	034229	Plate, Track Wiper		2
9	F05005-64	Stud, 1/4-20 x 5/8" Wing		2
10	F05005-68	Bolt, 1/4-20 x 1 3/4" Hex Head Grade 5		2
11	F05011-11	Washer, 1/4" SAE Flat		5

REF	PART #	DESCRIPTION	COMMENTS	QTY.
12	F05010-31	Nut, 1/2-13 Jam	Replaced 065724 Lower Stop Spring Retainer Pin, 036713 Spring and F05012-9 Cotter Pin used on LT35 Rev. A1.01-A6.05/LT35HD Rev. A1.02-A6.06 (LT35 Rev. A6.06/LT35HD Rev. A6.07).	1
13	F05005-15	Bolt, 1/4-20 x 1/2" Hex Head		2
	048547	Bearing Assembly, Lower LT28		1
14	048548	Bearing Weldment, LT28 Lower Cam		1
15	012797	Bearing, Cam Follower 1 1/2 (McGill)		1
16	F05010-11	Nut, 5/8-18 Hex Jam		1
17	F05007-87	Bolt, 3/8-16 x 1" Hex Head Grade 5		4
18	F05007-123	Bolt, 3/8-16 x 1 1/4" Hex Head Grade 5		4
19	F05010-10	Nut, 3/8-16 Hex Nylon Lock		8
20	F05010-31	Nut, 1/2-13 Hex Jam		1
21	F05008-33	Bolt, 1/2-13 x 1 1/2" Hex Head Grade 5		1
22	F05007-92	Bolt, 3/8-16 x 4" Hex Head Full Thread Grade 5		2
23	F05011-3	Washer, 3/8" SAE Flat		12
24	F05010-10	Nut, 3/8-16 Hex Nylon Lock		10
25	F05010-58	Nut, 5/16-18 Nylok Hex		3
26	F05011-17	Washer, 5/16" SAE Flat		6
27	F05006-5	Bolt, 5/16-18 x 3/4" Hex Head		3
28	017778	Pointer, Scale Height		1
29	F05004-3	Bolt, #10-24 x 3/8" CrSI PH		2
30	F05010-14	Nut, #10-24 Keps		2
31	038482	Clamp, 1-1/4 Carbon Steel Conduit		1
32	F05011-14	Washer, 1/4" Split Lock		1
33	F05005-15	Bolt, 1/4-20 x 1/2" Hex Head		1
34	048614	Angle, LT28 Mast Tube Stainless		4
	P05035	Collar, 5/8" x 1-1/8" Lock		2
35	P05035-1	Collar, 5/8" x 1-1/8" Lock		1
36	F05005-105	Screw, 1/4-28 x 1/4" BO SH Cup Set		1
37	F05007-87	Bolt, 3/8-16 x 1" Hex Head Grade 5		2
38	F05007-123	Bolt, 3/8-16 x 1 1/4" Hex Head Grade 5		2
39	F05008-33 ¹	Bolt, 1/2-13 x 1 1/2" Hex Head Grade 5		1
	110614	Cover Assembly, LT28/35/70 Track	Replaced 049135 Wiper Assembly with S09915 Felt (12/18).	1
40	110610	Cover, Mid Track, LT28, LT35, LT70		1
41	110611	Retainer, Felt Oiler		1
42	F05005-113	Bolt, 1/4-20x3/4 Carriage		4
43	F05010-69	Nut, 1/4-20 Nylock		4
44	F05011-11	Washer, 1/4 SAE Flat		4
45	S09915	Felt, Middle Track Oiler LT40/50/70		1
46	S11762	DECAL, SAW HEAD UP/DOWN CAUTION		1


9.2 Power Feed Assembly

LT35

Rev. A4.00+

LT35HD

Rev. A4.00+



3H1132C

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	066999	POWER FEED ASSEMBLY, LT35		1
	066990	Feed Assembly, LT35 Saw Head Power		1
1	066991	Mount Weldment, LT35 Power Feed		1
2	P06030-1	Bearing, 5/8" x 1.5748 x .4724		2
	079800	Shaft Upgrade, Power Feed	079800 replaced 016067 Power Feed Shaft Assembly with S31027 Key to improve durability (LT35 Rev. A6.11/LT35HD Rev. A6.13). Modified 079798 Power Feed Shaft with threaded end and added (1) F05010-101 Jam Nut and (1) 079799 Spacer.	1
3	079798	Shaft Weldment, Power Feed, Threaded	Available in assemblies only.	1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
4	079799	Spacer, Bearing, Power Feed		1
5	F05010-101	Nut, 5/8-18 Nyl Jam		1
6	S31027	Key, 3/16" Square x 1" Long		1
7	P04031	Belt, 4L280		1
8	P04343	Sheave, 8A x 5/8"		1
9	W11613	Cover Weldment, Power Feed		1
10	F05005-32	Screw, 1/4-20 x 2 1/4" Hex Head		2
11	F05011-14	Washer, 1/4" Split Lock		5
12	S09579	Shave, 1 3/4" Feed Motor		1
13	F05007-12	Screw, 3/8-16 x 1/2" SH Cup		2
14	F05005-101	Bolt, 1/4-20 x 1" Hex Head Grade 5		1
15	F05011-11	Washer, 1/4" SAE Flat		3
16	F05010-11	Nut, 5/8-18 Hex Jam		1
17	F05011-5	Washer, 5/8" SAE Flat		6
18	012797	Bearing, Cam Follower 1 1/2"		1
19	024431	Decal, Disconnect Motor Leads Warning		1
20	006747	Motor, 1/2HP 12VDC		1
	061794	Brush Kit, 12V Motor		1
21	F05011-3	Washer, 3/8" Sae Flat		2
22	F05011-36	Washer, 3/8" Star External		2
23	F05007-82	Bolt, 3/8-16 x 1" Hex Head Grade 8		2
24	066995	Mount Weldment, Power Feed Motor		1
25	066998	Plate, Power Feed Drive		1
26	F05007-123	Bolt, 3/8-16 x 1 1/4" Hex Head Grade 5		1
27	F05011-3	Washer, 3/8" Sae Flat		4
28	F05010-10	Nut, 3/8-16 Hex Nylon Lock		3
29	F05007-127	Bolt, 3/8-16 x 1 1/4" Carriage Head Grade 5		2


9.3 Power Feed Assembly

LT35

Rev. A1.00 - A3.00


LT35HD

Rev. A1.00 - A3.00



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	065078	POWER FEED ASSEMBLY, LT35		1
1	008958	Boss, .63" ID X 1" OD X .85"		1
2	008959	Bolt, Idler Sprocket Retaining		1
3	008973	Bracket, Power Feed Drive Mount		1
4	059593	Plate, Power Feed Drive Mount		1
5	059594	Sprocket, 40B28 x 3/4" Bore		1
6	069361	Motor Assembly, LT28 Power Feed		1
	065182	Brush Kit, Klauber 33:1 Gearmotor End-bell		1
7	F05006-102	Bolt, 5/16-18 x 3/4" Hex Head Grade 5		4
8	F05011-13	Washer, 5/16" Split Lock		4
9	F05007-123	Bolt, 3/8-16 x 1 1/4" Hex Head Grade 5		1
10	F05007-127	Bolt, 3/8-16 x 1 1/4" Carriage Head Grade 5		2
11	F05011-3	Washer, 3/8" Sae Flat		4
12	F05010-10	Nut, 3/8-16 Hex Nylon Lock		3
13	P04333	Sprocket, #40 17T x 5/8" Bore Idler		1
14	F05010-34	Nut, 5/8-11 Hex Nylon Lock		1


9.4 Feed Chain/Stop



REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	014745	CHAIN, #40 X 267.5" LT40 FEED		1
2	P04200	LINK, #40 MASTER		2
3	015721	TENSIONER WELDMENT, POWER FEED CHAIN		1
4	F05011-2	WASHER, 1/2" SAE FLAT		3
5	F05011-9	WASHER, 1/2" SPLIT LOCK		3
6	F05008-128	BOLT, 1/2-13 X 1" HEX HEAD GRADE 8		3
7	F05010-16	NUT, 1/2-20 HEX JAM		2
8	F05011-9	WASHER, 1/2" SPLIT LOCK		2
9	006686	BRACKET WELDMENT, REAR FEED STOP		1
	K09630	STOP KIT, RUBBER CARRIAGE		2
10	P12165	Stop, Rubber Carriage		1
11	W09293	Pin, Rubber Carriage Stop		1
12	F05012-21	Pin, 3/16" X 1" Cotter		1
13	F05005-134	BOLT, 1/4-20 X 3/4" WITH CONICAL WASHER		1
14	057822	PLATE, BED TUBE END W/LIGHT MOUNT		1
15	015008	BRACKET, FRONT FEED CHAIN MOUNT		1
16	F05007-87	BOLT, 3/8-16 X 1" HEX HEAD GRADE 5		2
17	F05010-10	NUT, 3/8-16 HEX NYLON LOCK		2
18	006688	GROMMET, 6 1/2" LIGHT MOUNTING		1
19	006391	LIGHT, 8 DIODE LED TAIL		1


SECTION 10 BED FRAME ASSEMBLY

10.1 Bed Rail Assembly, Front And Rear




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	079144	Kit, Front/Rear Bed Rail SS Cover	Service Kit	1
1	F05010-6	Nut, 5/16-18 Swaged Hex		6
2	016898	Cover, 36-1/4 Rail SS		2
3	F05006-10	Bolt, 5/16-18x2 1/2 HH Gr2		6
4	014455	Bedrail Weldment, 1996 Front Hyd	Front	1
	014467	Bedrail Weldment, 1996 Rear Hyd	Rear	
5	F05011-2	Washer, 1/2 SAE Flat		7
6	F05008-78	Bolt, 1/2-13 x 4 HHB GR5 ZINC	Front	3
	F05008-94	Bolt, 1/2-13x3 1/2 Carriage	Rear	1
7	F05010-8	Nut, 1/2-13 Nyl Hex Lock		4
8	F05010-5	Nut, 5/8-11 Hex		4
9	S13006	Bolt, Bed Rail Adj LT50		4
10	038843	Plate, Formed 2x4 Bed Cap		1
11	F05005-134	Bolt, 1/4-20x3/4 W/Conical Washer		1
12	015970	Wrench, Bed Rail Adjustment	OPTIONAL	1

10.2 Bed Rail Assembly, Middle Front




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	03454SAE	BED RAIL ASSEMBLY, FRONT MIDDLE (LT60/70 BED 2)		1
1	034545	Bed Rail Tube, Short	Available in assemblies only.	1
2	F05010-5	Nut, 5/8-11 Hex		2
3	S13006	Bolt, Bed Rail Adjustment		2
4	S04058	Plate, Bed Rail End Cap	Available in assemblies only.	2
5	F05008-78	Bolt, 1/2-13 X 4" Hex Head Grade 5		2
6	F05011-2	Washer, 1/2" SAE Flat		4
7	F05010-8	Nut, 1/2-13 Nylon Lock		2
	A0SAESAE56	Cover Assembly, Stainless Steel Bed Rail (Long)		1
8	S0SAESAE44	Cover, Stainless Steel Bed Rail	Available in assemblies only.	1
9	F05006-10	Bolt, 5/16-18 X 2 1/2" Hex Head		3
10	F05010-6	Nut, 5/16-18 Hex Lock		3
11	015SAE70	WRENCH, BED RAIL ADJUSTMENT		1

10.3 Bed Rail Assembly, Middle Rear




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	015757	BED RAIL ASSEMBLY, REAR MIDDLE PAINTED		1
1	014640	Bed Rail Tube, Short	Available in assemblies only.	1
2	014639	Block, Log Stop w/Threaded Hole	Available in assemblies only.	1
3	F05007-17	Bolt, 3/8-16 x 1 1/2 Full Thead Hex Head		1
4	F05010-29	Nut, 3/8-16 Hex Jam		1
5	F05010-187	Nut, 5/8-11 Square Pilot Weld		2
6	F05010-5	Nut, 5/8-11 Hex		2
7	S13006	Bolt, Bed Rail Adjustment		2
8	S04058	Plate, Bed Rail End Cap		1
9	F05008-78	BOLT, 1/2-13 X 4" HEX HEAD GRADE 5		2
10	F05011-2	WASHER, 1/2" SAE FLAT		4
11	F05010-8	NUT, 1/2-13 NYLON LOCK		2
	A09956	COVER ASSEMBLY, STAINLESS STEEL BED RAIL (LONG)		1
12	S09944	Cover, Stainless Steel Bed Rail	Available in assemblies only.	1
13	F05006-10	Bolt, 5/16-18 X 2 1/2" Hex Head		3
14	F05010-6	Nut, 5/16-18 Hex Lock		3
15	015970	WRENCH, BED RAIL ADJUSTMENT		1

10.4 Optional Legs Assembly ()




REF	PART #	DESCRIPTION	COMMENTS	QTY.
		See Form #847 or diagram below for stationary sawmill foot anchor locations		
		See Form #35SAE for stationary sawmill w/bed extension foot anchor locations		
1	W0SAE513	LEG, LONG STATIONARY		3
2	0150SAE1	LEG, LONG STATIONARY W/BOARD RETURN TABLE BRACKET		1
3	F05007-113	BOLT, 3/8-16 X 5" CARRIAGE HEAD		12
4	F05007-2	BOLT, 3/8-16 X 1 1/4" HEX HEAD		4
5	F05011-3	WASHER, 3/8" SAE FLAT		16
6	F05010-10	NUT, 3/8-16 HEX NYLON LOCK		16
7	W0SAE515	LEG, SHORT STATIONARY		2
8	F05007-2	BOLT, 3/8-16 X 1 1/4" HEX HEAD		8
9	F05010-10	NUT, 3/8-16 HEX NYLON LOCK		8
10	W0SAE517	LEG, FRONT STATIONARY		1
11	065SAE35	Leg Weldment, Festoon Stationary Front		1
12	F05008-88	Bolt, 1/2-13 x 1 3/4" Full Thread Hex Head Grade 5		1
13	F05010-3	Nut, 1/2-13 Swaged Hex		1
14	F05010-35	Nut, 1/2-13 Free Hex		1
15	F05011-2	Washer, 1/2" SAW Flat		2
16	F05011-SAE	Washer, 1/2" Split Lock		1
17	F0500SAE-11	BOLT, 5/8-11 X 5 1/2" HEX HEAD GRADE 5		2
18	F05010-4	NUT, 5/8-11 HEX LOCK		2

10.6 Log Side Support Assembly




REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	015235	SUPPORT, LOG SIDE		2
2	P04107	Fitting, 3/16" Grease		2
	01655SAE	MOUNTING KIT, LOG SIDE SUPPORT		2
3	016544	Pin, Log Side Support Pivot		1
4	F05005-4	Bolt, 1/4-20 X 1 1/2" Hex Head Grade 5		1
5	F05011-11	Washer, 1/4" SAE Flat		2
6	F05010-SAE	Nut, 1/4-20 Self Locking		1
7	016555	Plate, Log Side Support End		1
8	F05008-61	Bolt, 1/2-13 X 3 1/2" Hex Head Grade 5		2
9	F05011-2	Washer, 1/2" SAE Flat		5
10	F05010-8	Nut, 1/2-13 Hex Nylon Lock		3
11	014632	Washer, .52" x 1.6SAE"		1
12	F05008-33	Bolt, 1/2-13 X 1 1/2" Hex Head Grade 5		1
13	016558	Plate, Side Support Washer Clamp		1
	0167SAE8	GUARD KIT, STAINLESS STEEL SIDE SUPPORT		1
14	016722	Guard, Stainless Steel Side Support		4
15	F05005-4	Bolt, 1/4-20 x 1 3/4" Hex Head		8
16	F05011-11	Washer, 1/4" SAE Flat		16
	F05011-5	Washer, 5/8" SAE Flat		4
17	F05010-6SAE	Nut, 1/4-20 Hex Nylon Lock		8
	0167SAE8-1005	Instruction Sheet		1
	016562	ROLLER KIT, SIDE SUPPORT	(OPTIONAL FOR MANUAL)	2

10.7 Safety Chain Assembly




REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	107SAE72	CHAIN, 15 INCH SAFETY		1
2	F05008-33	BOLT, 1/2-13X1 1/2 HEX HEAD GRADE 5		1
3	F05010-8	NUT, 1/2-13 NYLON HEX LOCK		1
4	F05011-35	WASHER, 7/16 STANDARD FLAT		1

10.8 Saw Head Rest Pin Assembly




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	079485	Pin Assy, Rest, 40/50		
	079511	Pin Assy, Rest, 40/50 Hyd Wide		
1	014102	Pin Weldment, C-Frame Rest 96 Hyd		1
	079510	Pin Wldmt, Rest, 40/50 Hyd Wide		1
2	014151	Pin, 3/8x2 1/4 Sq Wire Lock		1
3	F05008-74	Bolt, 1/2-13 x 2 1/2" Hex Head Grade 5	F05008-74 was F05008-10; two washers added after 5/14/2021, ECN 37840.	1
4	F05011-2	Washer, 1/2 SAE Flat		4
5	F05010-3	Nut, 1/2-13 Swaged Hex		1

10.9 Bed Frame Decals



REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	065034	DECAL, WHITE WOOD-MIZER EURO LOGO		1
2	065035	DECAL, HYDRAULIC EURO LOGO BLACK STD.		1
3	P07453	DECAL, AMBER REFLECTIVE 2" ROUND		2
4	S09851	DECAL, KEEP AWAY DANGER		1
5	P07452	DECAL, RED REFLECTIVE 2" ROUND		3
6	P10287	DECAL, PINCH POINT DANGER		1
7	S12581	DECAL, SAW HEAD REST CAUTION		1
8	S12051	DECAL, LOG LIMIT STRIPE		2
9	P12961	DECAL, KEEP AWAY HYDRAULIC WARNING		1

10.10 Board Outfeed Table (Optional)




SM0316

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	016652	TABLE ASSEMBLY, BOARD OUTFEED		1
1	016606	Table Weldment, Board Outfeed		1
2	038167	Roller, 2 1/2" x 25"		6
3	016609	Mount Weldment, Outfeed Table Leg		2
4	016651	Leg Weldment, Outfeed Table		4
5	014151	Pin, 3/8" x 2 1/4" Square Wire Lock		4
6	016677	Pin, Snap - Coil Tension		4
7	F05004-123	Bolt, 3/8-16x3 1/2 HH Gr5		4
8	F05010-222	Nut, 3/8-16 Flanged Hex Nylock		4
9	F05011-3	Washer, 3/8 Flat SAE		4
10	S12641	Decal, Hand Pinch Point Warning		4
11	015882	Decal, Wood-Mizer Logo 10.25"		2


SECTION 11 BED HYDRAULIC SYSTEM

11.1 Hydraulic Hoses



REF	COLOR	LENGTH "A"		DESCRIPTION (NOTE: See Hydraulic Information Section in Operator's Manual for Hydraulic Schematics)	PART #	QTY.
		MFG SPEC	ACTUAL PART			
H1	None	9"	9"	1/4" Hydraulic Pump To Valve	079000-9	1
H2	Plain	27"	27"	Log Turner Base	079000-27	1
H3	Orange	18"	18"	Log Turner Top	079000-18	1
H4	Yellow	95"	95"	Front Toe Board Top (LT30HD)	079000-95	1
		117"	117"	Front Toe Board Top (LT40HD)	079000-117	1
H5	Gray	95"	95"	Front Toe Board Base (LT30HD)	079000-95	1
		117"	117"	Front Toe Board Base (LT40HD)	079000-117	1
H6	Pink	159"	159"	Side Support Base (LT30HD)	079000-159	1
		181"	181"	Side Support Base (LT40HD)	079000-181	1
H7	Plain	159"	159"	Side Support Top (LT30HD)	079000-159	1
		181"	181"	Side Support Top (LT40HD)	079000-181	1
H8	White	133"	135"	Clamp In/Out Top (LT30HD)	079000-135	1
		155"	157"	Clamp In/Out Top (LT40HD)	079000-157	1
H9	Dark Orange	125"	125"	Clamp In/Out Base (LT30HD)	079000-125	1
		147"	151"	Clamp In/Out Base (LT40HD)	079000-151	1
H10	Purple	197"	196"	Rear Toe Board Top (LT30HD)	079000-196	1
		219"	219"	Rear Toe Board Top (LT40HD)	079000-219	1
H11	Black	197"	196"	Rear Toe Board Base (LT30HD)	079000-196	1
		219"	219"	Rear Toe Board Base (LT40HD)	079000-219	1
H12	Green	62"	62"	Loading Arm Branch Top	079000-62	2
H13	Yellow	64"	64"	Loading Arm Branch Base	079000-64	2
H14	Blue	164"	164"	Loading Arm Top (LT30HD)	079000-164	1
		186"	186"	Loading Arm Top (LT40HD)	079000-186	1
H15	Red	164"	164"	Loading Arm Bottom (LT30HD)	079000-164	1
		186"	186"	Loading Arm Bottom (LT40HD)	079000-186	1
H16	Green	182"	181"	1/4" Clamp Up/Down Top (LT30HD)	079000-181	1
		204"	204"	1/4" Clamp Up/Down Top (LT40HD)	079000-204	1
H17	Yellow	171"	173"	1/4" Clamp Up/Down Base (LT30HD)	079000-173	1
		193"	194"	1/4" Clamp Up/Down Base (LT40HD)	079000-194	1
				Grommet, 2 1/2" Diameter Rubber	085614	2
				Grommet, 1 x 1 3/4" Oval Rubber	085613	2

11.2 Hydraulic Control Box



REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	015027	BOX WELDMENT, SUPER HYDRAULIC PUMP HOUSING		1
2	015228	COVER, SUPER HYDRAULIC PUMP HOUSING TOP		1
3	015227	COVER, SUPER HYDRAULIC PUMP HOUSING SIDE		1
4	061764	PUMP KIT, HYDRAULIC W/MOTOR		1
	016199	Pump, Hydraulic Replacement Monarch Model #12070		1
	052807	Motor Kit, Hydraulic Replacement		1
5	038683	Motor, 12 VDC Hydraulic Pump #08714 (Iskra)	Available in assemblies only.	1
	038682	Brush Kit, 4-Valve Hydraulic Pump Motor #08658-I (Iskra)		1
	P12513	Bearing, Base Motor #02318		1


REF	PART #	DESCRIPTION	COMMENTS	QTY.
6	052806	Wire Assembly, Motor Brush Ground		1
7	P12817	Cap, Hydraulic Pump Vented Fill #03171		1
	P10198	O-Ring, Hydraulic Pump/Reservoir #02352		1
	P10315	Seal, Hydraulic Pump/Motor #02330		1
8	016371	SOLENOID KIT, 200A 12V SPST HYDRAULIC PUMP MOTOR		1
	015470	Solenoid, 200A 12V SPST Cont. Duty	Available in assemblies only.	1
	015426	Diode Assembly, Solenoid Coil Chassis Gnd		1
9	F05010-9	NUT, 1/4-20 SELF-LOCKING HEX		2
10	F05011-11	WASHER, 1/4" SAE FLAT		2
11	F05005-1	BOLT, #1/4-20 X 3/4" HEX HEAD FULL THREAD		2
12	F05011-37	WASHER, 1/4" EXTERIOR STAR LOCK		2
	P12742	FLUID, 1-QUART DEXRON III HYDRAULIC		2 1/4 gal.
	006397	FLUID, 1-GALLON CONOCO MV32		2 1/4 gal.
	P12822	FLUID, 1-GALLON EXXON UNIVIS HVI 13HY-DRAULIC		2 1/4 gal.
13	F05007-87	BOLT, 3/8-16 X 1" HEX HEAD GRADE 5		8
14	F05007-113	BOLT, 3/8-16 X 5" CARRIAGE HEAD		4
15	F05011-3	WASHER, 3/8" SAE FLAT		10
16	F05011-4	WASHER, 3/8" SPLIT LOCK		4
17	F05011-36	WASHER, 3/8" EXTERNAL STAR LOCK		4
18	F05010-10	NUT, 3/8-16 HEX NYLON LOCK		4
19	F05007-2	BOLT, 3/8-16 X 1 1/4" HEX HEAD		2
20	015260	VALVE, HYDRAULIC 6 SECTION (See Form 575 For Valve Service Parts)		1
21	P26284	FITTING, 3/8" O-RING - 1/4" JIC		8
22	015488	FITTING, #6 SAE - 1/4" JIC 45° ELBOW		4
23	014686	FITTING, #6 SAE MALE - 1/4" NPT FEMALE		1
24	014685	FITTING, 1/4" NPT X 3/8" HOSE BARB		1
25	P12739	CLAMP, 11/16" HOSE		5
26	P26284	FITTING, 3/8" O-RING - 1/4" JIC		1
27	024198	SWITCH, HYDRAULIC VALVE ELECTRIC		1
28	F05004-13	SCREW, #4-40 X 3/4" SLOTTED		2
29	F05011-21	WASHER, #4 SPLIT LOCK		2
30	F05010-43	NUT, #4-40 HEX		2
31	F05007-7	BOLT, 3/8-16 X 1" HEX HEAD		2
32	F05010-10	NUT, 3/8-16 HEX NYLON LOCK		2
33	015079	SEAL, RUBBER VALVE HANDLE		1
34	015078	PLATE, VALVE HANDLE DECAL		1
35	F05015-7	SCREW, #10-24 X 1/2 SLOTTED HEX SELF-TAP- PING		8
36	F05010-14	NUT, #10-24 SELF-LOCKING HEX		2
37	015364	DECAL, 1997 HYDRAULIC CONTROL BOX		1
38	P22683	MANIFOLD, HYDRAULIC CARTRIDGE FILTER		1
39	P20301	Filter, S28 Hydraulic Cartridge		1
40	P12707	FITTING, #6-8 (1/2" NPT) - 3/8" HOSE BARB ELBOW		2
41	P12708	FITTING, #6-6 (3/8" NPT) - 3/8" HOSE BARB ELBOW		2

1 Bed Hydraulic System

Hydraulic Control Box

REF	PART #	DESCRIPTION	COMMENTS	QTY.
42	015490	FITTING, 3/8" NPT MALE - 1/4" NPT FEMALE		1
43	P09142	FITTING, 1/4" NPT - 1/4" JIC ELBOW		1
44	F05005-15	BOLT, 1/4-20 X 1/2" HEX HEAD		2
45	F05011-14	WASHER, 1/4" SPLIT LOCK		2
46	R01892-1	HOSE, 3/8" LOW PRESSURE HYDRAULIC		A/R
47	036315	WIRE ASSEMBLY, 14 GA X 4" #10 & 5/16" RINGS		1
48	036310	CABLE ASSEMBLY, 1 GA X 16" HYDRAULIC PUMP TO SOLENOID		1
49	036312	CABLE ASSEMBLY, 1 GA X 16" HYDRAULIC PUMP GROUND		1
50	036778	PLUG, 1 3/32 NYLON	ECN:38166;	2
	F05011-36	WASHER, 3/8" STAR EXTERNAL		2

11.3 Hydraulic Power Supply Strip




REF	PART #	DESCRIPTION	COMMENTS	QTY.
	010103	CONTACT ASSEMBLY, HYDRAULIC POWER SUPPLY (POSITIVE)		1
	007716	Contact Kit, 97+ Hydraulic Power Supply Positive		1
1	015253	Contact, Hydraulic Power Supply (Positive)	Available in assemblies only.	1
2	P10077	Spring, Positive Contact		2
3	F05006-143	Bolt, 5/16" x 3/4" Shoulder (1/4-20 Thread) Stainless		2
4	F05006-20	Bolt, 5/16-18 x 1/2" Socket Button Head		1
5	S10072	Insulator, Positive Contact		1
6	015324	Bracket, Positive Contact Mounting		1
7	F05011-11	Washer, 1/4" SAE Flat		2

REF	PART #	DESCRIPTION	COMMENTS	QTY.
8	128088	Cable Assembly, 1AWG Red x13 (2x5/16 Term)	Cable assemblies replaced R01971 and F05092-16 after 9/17/2019 per ECN 37793.	1
	R01971	Cable, #1 Weld	Available in assemblies only.	1 Ft
	F05092-16	Terminal, 5/16" Ring #2 Gauge		2
9	F05005-38	Bolt, 1/4-20 x 1" Hex Head Grade 2		2
10	F05010-9	Nut, 1/4-20 Hex Self-Locking		2
11	F05007-11	Bolt, 3/8-16 x 1 1/4" Carriage Head		2
12	F05010-10	Nut, 3/8-16 Hex Nylon Lock		2
	065081	CONTACT ASSEMBLY, LT35 HYDRAULIC POWER SUPPLY (GROUND)		1
13	F05011-3	Washer, 3/8" SAE Flat		4
14	F05010-10	Nut, 3/8-16 Hex Nylon Lock		2
15	F05007-7	Bolt, 3/8-16 x 4" Square Head		2
16	016792	Bracket, Ground Contact Mounting		1
17	036306	Cable Assembly, 1AWG Blk x26 (2x5/16 Term)	Cable assemblies replaced R01971 and F05092-16 after 9/17/2019 per ECN 37793.	1
	R01971	Cable, #1 Weld	Available in assemblies only.	1 Ft
	F05092-16	Terminal, 5/16" Ring #2 Gauge		1
	007717	Contact Kit, Hydraulic Ground 1997+		1
18	015264	Contact, Hydraulic Power Supply (Ground)	Available in assemblies only.	1
19	F05008-96	Bolt, 5/16-18 x 1 1/2" Hex Head Grade 5		2
20	P10077	Spring, Ground Contact		2
21	F05010-17	Nut, 5/16-18 Hex		2
22	F05011-17	Washer, 5/16" SAE Flat		2
23	025964	PLATE, LT35 POSITIVE CONTACT SPACER		1
24	059636	PLATE, LT35 CONTACT MOUNT		1
25	F05011-3	WASHER, 3/8" SAE FLAT		3
26	F05010-10	NUT, 3/8-16 HEX NYLON LOCK		3
27	F05007-7	BOLT, 3/8-16x1 HHC		3
	A11977	STRIP ASSEMBLY, 6 FT. CONTACT	Replaces 065046 Short Contact Strip Assembly including 065044 Contact Strip Housing and 065045 1/8" x 1" x 15-13/16" Contact Strip (Rev. A4.00). Use 065046 Short Contact Strip Assembly to service LT35/LT35HD prior to Rev. A4.00. (NOTE: A11977 Contact Strip Assembly is too long and cannot be used on LT35/LT35HD prior to Rev. A4.00. Damage to sawmill may result.)	1
28	F05015-1	Bolt, 1/4-20 x 1/2" Self Tap HH		2
29	P11976	Housing, Contact Strip		1
	A12043-N	Strip, Hydraulic Contact w/Cable		1
30	S10075	Strip, 1/8" x 1" x 69-13/16" Contact	Available in assemblies only.	1
31	052161	Cable Assembly, 1AWG Blk x36 (2x5/16 Term)	Cable assemblies replaced R01971 and F05092-16 after 9/17/2019 per ECN 37793.	1
	R01971	Cable, 1AWG SO Welding	Available in assemblies only.	1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	F05092-16	Terminal, 5/16" 1-2Ga Ring NI Loose		2
32	F05006-45	Screw, 5/16-18 x 3/4" Black Nylon HHC		1
33	F05010-86	Nut, 5/16-18 Black Nylon Hex		1
34	R01950-8	Tubing, 5/8" Heat Shrink w/Adhesive ID		1
	A12043-406	Instruction Sheet, Strip Replacement		1
35	P04137	Grommet, 5/8" Wire		1


11.4 Hydraulic Log Loader



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	LTHDLA-30H	LOADER KIT, HYDRAULIC LOG (LT30HD ONLY)		1
	LTHDLA	LOADER KIT, HYDRAULIC LOG (LT35HD & LT40HD ONLY)		1
	036416	Arm Assembly, Hydraulic Log Loading		1
1	110372	Arm Weldment, Log Loading		1
2	P04107	Fitting, 3/16" Grease		2
3	110472	Chain, 12-1/2 Inch Safety		1
4	F05008-146	Bolt, 1/2 x 1 Shoulder Socket		1
5	F05010-10	Nut, 3/8-16 Hex Nyloc		1
6	F05011-3	Washer, 3/8 Flat SAE		1
7	W09444	Channel, Hydraulic Log Loading Foot		2
8	P04107	Fitting, 3/16" Grease		4
	A09284	Cylinder Assembly, Hydraulic Log Loading Arm	Available in assemblies only.	2
9	P12847	Cylinder, 8" X 3" Hydraulic		1


REF	PART #	DESCRIPTION	COMMENTS	QTY.
	P12956	Seal Kit, 8" x 3" Hydraulic Cylinder		1
10	P09143	Fitting, C5205x4x4 Male Connector		2
11	P12199	Fitting, 0455x4x4 90° Swivel Elbow		1
	015832	Fitting Kit, 1/4NPT 5.0GPM Velocity Fuse		1
12	015750	Fitting, 1/4NPT 5.0GPM Velocity Fuse	Available in assemblies only.	2
	015832-255	Instruction Sheet, Velocity Fuse Replacement		1
13	W09446	Pin, Loading Arm Mount		4
14	F05005-1	Bolt, 1/4-20 x 3/4" Hex Head Full Thread		4
15	F05010-69	Nut, 1/4-20 Hex Lock		4
16	S09251	Pin, Loading Arm Cylinder Mount		2
17	F05011-28	Washer, 1" SAE Flat		4
18	F05012-23	Pin, 3/16" X 1 1/2" Cotter		4
19	P09145	Fitting, C5705x5x4 Union 'T'		2
20	S09245	Clamp, 1/4" Hydraulic Hose		6
21	F05006-102	Bolt, 5/16-18 X 3/4" Hex Head Grade 5		6
22	F05008-116	BOLT, 1/2-13 X 2" HEX HEAD FULL THREAD GRADE 5		2
23	F05010-31	NUT, 1/2-13 JAM		2

11.5 Hydraulic Log Turner



REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	015231	ARM, HYDRAULIC LOG TURNER LINK		1
2	P04107	Fitting, 3/16" Grease		2
3	015233	ARM, HYDRAULIC LOG TURNER PAINTED		1
4	014675	CLAW, HYDRAULIC LOG TURNER		2
5	F05008-28	BOLT, 1/2-13 X 5 1/2" HEX HEAD GRADE 5		2
6	F05010-8	NUT, 1/2-13 NYLON HEX LOCK		2
7	015085	PIN, LOG TURNER MOUNT		2
8	F05006-1	BOLT, 5/16-18 X 1" HEX HEAD GRADE 2		2
9	F05010-6	NUT, 5/16-18 HEX LOCK		2
10	S09246	PIN, LOG TURNER PIVOT		1
11	F05011-28	WASHER, 1" SAE FLAT		2
12	F05012-23	PIN, 3/16" X 1 1/2" COTTER		2
13	015718	SPRING, HYDRAULIC LOG TURNER		2
14	S09155	PLATE, LOG TURNER CYLINDER MOUNT		1
15	S09109	PLATE, LOG TURNER MOUNT		2
16	S09605	PLATE, LOG TURNER BRACE		2
	A09286	CYLINDER ASSEMBLY, HYDRAULIC LOG TURNER		1
17	P12846	Cylinder, 8" X 2 1/2" Hydraulic	Available in assemblies only.	1
	P12955	Seal Kit, 8" x 2 1/2" Hydraulic Cylinder		1
18	P09142	Fitting, 90° Male Elbow		2
19	F05011-2	WASHER, 1/2" SAE FLAT		4

11.6 Hydraulic Log Side Supports (Front/Rear)




REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	015010	Support Weldment, Log Side		2
2	016544	Pin, Log Side Support Pivot		2
3	016555	Plate, Log Side Support End		2
4	F05008-61	Bolt, 1/2-13 X 3 1/2" Hex Head Grade 5		4
5	F05011-2	Washer, 1/2" SAE Flat		10
6	F05010-8	Nut, 1/2-13 Hex Nylon Lock		6
7	F05008-33	Bolt, 1/2-13 X 1 1/2" Hex Head Grade 5		2
8	014632	Washer, .52" x 1.69"		2
9	016558	Plate, Side Support Washer Clamp		2
10	P04107	Fitting, 3/16" Grease		4
	A09283	Cylinder Assembly, Hydraulic Log Side Support		2
11	P12845	Cylinder, 6" X 2" Hydraulic		1
	P12954	Seal Kit, 6" x 2" Hydraulic Cylinder	Service parts	1
12	P09142	Fitting, 90° Male Elbow		2
13	P09140	Fitting, C3529x4 90° Pipe		2
14	P09141	Fitting, C3759x4 Male 'T'		2
15	P09143	Fitting, C5205x4x4 Male Connector		2
16	015484	Valve, Hydraulic Sequence		2
17	015490	Fitting, 3/8" NPT - 1/4" NPT Reducer		4

11 Bed Hydraulic System

Hydraulic Log Side Supports (Front/Rear)


REF	PART #	DESCRIPTION	COMMENTS	QTY.
18	015026	Rod, Hydraulic Side Support Link	(See Section 11.7) if equipped with HSS Option	1
19	P09137	End, 1/2" Rod		2
20	F05008-10	Bolt, 1/2-13 X 2 1/4" Hex Head Grade 5		2
21	F05011-2	Washer, 1/2" SAE Flat		4
22	F05010-8	Nut, 1/2-13 Hex Nylon Lock		2
23	F05010-16	Nut, 1/2-20 Hex Jam		1
24	S09251	Pin, Cylinder Mount		2
25	F05011-28	Washer, 1" SAE Flat		4
26	F05012-23	Pin, 3/16" X 1 1/2" Cotter		4
	016562	Roller Kit, Side Support	Standard on hydraulic supports	2
27	016561	Roller, Side Support		2
28	F05011-5	Washer, 5/8" SAE Flat		6
29	F05009-118	Bolt, 5/8-11 x 3 3/4" Hex Head Grade 5		1
30	F05010-96	Nut, 5/8-11 Hex Nylon Lock Jam		1
31	016560	Bushing, Bronze 5/8" x 1" x 3/4"		2
	016798	Guard Kit, Stainless Steel Side Support	(Optional)	1
32	016722	Guard, Stainless Steel Side Support		4
33	F05005-4	Bolt, 1/4-20 x 1 3/4" Hex Head		8
34	F05011-11	Washer, 1/4" SAE Flat		16
	F05011-5	Washer, 5/8" SAE Flat	For extra spacing on the hydraulic supports	4
35	F05010-69	Nut, 1/4-20 Hex Nylon Lock		8
	016798-1005	Instruction Sheet, Stainless Steel Side Support Guard Retro		1

11.7 Hydraulic Log Side Supports (Middle - Optional)



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	HSS-A	Support Assembly, Hydraulic 4-Link Side		1
1	048436	Support Weldment, Front Log Side		1
2	048438	Support Weldment, Rear Log Side		1
3	048537	Rod, 4-Link Side Support		1
4	P09137	Rod End, 1/2 Male		2
5	F05010-16	Nut, 1/2-20 Hex Jam		1
	048247	Rod Assembly, 4-Link Side Support Short		2
6	048246	Rod, 4-Link Connecting		1
7	P09137	Rod End, 1/2 Male		2
8	F05010-16	Nut, 1/2-20 Hex Jam		1
9	F05008-23	Bolt, 1/2-13 x 3" Hex Head Grade 5		1
10	F05011-2	Washer, 1/2" SAE Flat		12
11	F05010-8	Nut, 1/2-13 Nylon Hex Lock		2
12	P04107	Fitting, 3/16 x 3/16 Straight Grease		4
13	F05008-158	Bolt, 1/2-13 x 3" Flat Head Plow Grade 5		1


11.8 Hydraulic Log Clamp



REF	PART #	DESCRIPTION	COMMENTS	QTY.
	017264	CLAMP ASSEMBLY, HYDRAULIC 2-PLANE		1
1	017265	Mount Weldment, Hydraulic Clamp Slide		1
2	017267	Link Weldment, Hydraulic Clamp		1
3	015057	Washer, 1/8" x 2 1/2" Hardened		5
4	F05011-28	Washer, 1" SAE Flat		8
5	S09251	Pin, 1" x 3.88"		2
6	F05012-23	Pin, 3/16" x 1 1/2" Cotter		6
7	015049	Bolt, 1-14 x 8 1/2" Hex Head Grade 8		1
8	017275	Cylinder, 3" x 7" Hydraulic		1
	061365	Seal kit for Bailey Cyl. 017275		
	P12956	Seal Kit, Hydraulic Cylinder	P129956 used for J-D Cyl. (Identify by notched gland retaining nut)	1
9	017274	Arm, Clamp Pivot		1
10	015088	Bushing, Clamp Slide		2
	017271	Wiper Assembly, Vertical Clamp Rod		1
11	017273	Wiper, Vertical Clamp Rod		1
12	017272	Flange, Vertical Clamp Rod Wiper		1

REF	PART #	DESCRIPTION	COMMENTS	QTY.
13	F05011-17	Washer, 5/16" SAE Flat		8
14	F05006-1	Bolt, 5/16-18 x 1" Hex Head		2
15	015043	Clamp Weldment, Vertical		1
16	F05010-141	Nut, 1-14 Nylon Lock		1
17	017270	Block, Hydraulic Clamp Slide		1
18	015050	Cylinder Weldment, Vertical Clamp Hydraulic		1
	061435	Seal kit for 1" Bailey Cyl. 015050	Used on Bailey Cyl. after 8/19	1
	016204	Seal Kit, Hydraulic Cylinder		1
	016204-1009	Instruction Sheet, Vertical Clamp Seal Replacement		1
19	074543	Fitting, 4SAE-4JIC 90° Elbow	Fitting, 1/4" NPT x 1/4" JIC Elbow P09142 was replace with 074543 as of 11/6/2020, per ECN 37711.	2
20	017242	Retainer, Clamp Bushing		3
21	F05006-5	Bolt, 5/16-18 x 3/4" Hex Head		6
22	F05008-39	Bolt, 1/2-13 x 2 1/2" Socket Head		2
23	P04107	Fitting, 3/16" Straight Grease		1
24	015072	Bolt, 1-14 x 3 3/4" Hex Head Grade 8 w/Hole		2
25	F05010-163	Nut, 1-14 Slotted Hex		2
26	015068	Plate, Log Clamp Mount		1
27	F05011-3	Washer, 3/8" SAE Flat		8
28	F05007-5	Bolt, 3/8-16 x 5" Hex Head		4
29	F05010-10	Nut, 3/8-16 Hex Nylon Lock		4
30	F05011-46	Washer, 7/8" Split Lock		1
31	F05014-2	Bolt, 7/8-14 x 2" Hex Head Grade 5		1
32	015491	Fitting, 1/4" NPT - 3/8" JIC Elbow		2
33	F05008-28	Bolt, 1/2-13 x 5 1/2" Hex Head Grade 5		2
34	F05010-8	Nut, 1/2-13 Hex Nylon Lock		2
	K09485	Clamp Stop Kit, Hydraulic Log		1
35	W09404	Plate, Clamp Stop		1
36	F05008-33	Bolt, 1/2-13 X 1 1/2" Hex Head Grade 5		2
37	F05011-2	Washer, 1/2" SAE Flat		2
38	F05010-3	Nut, 1/2-13 Hex Lock		2

11.9 Hydraulic Toe Board



REF	PART #	DESCRIPTION	COMMENTS	QTY.
1	074842	Toe Board Assembly, Hydraulic		2
2	F05012-82	Pin, 1/2-1 3/4 Clevis		4
3	F05011-2	Washer, 1/2" SAE Flat		4
4	F05012-3	Pin, 1/8 x 3/4" Cotter		4
5	F05009-33	Bolt, 5/8-11 x 1 3/4" Hex Head		4
6	F05011-27	Washer, 5/8" Split Lock		4
7	S13023	Plate, Hydraulic ToeBoard Mount		2
8	S13022	Bracket, Hydraulic Toeboard Mount		2
9	S09251	Pin, Cylinder Mount		2
10	F05012-23	Pin, 3/16" x 1 1/2" Cotter		4
11	F05011-28	Washer, 1" SAE Flat		6
12	014482	Cylinder, 1 1/2" x 6" Hydraulic Toe board		2
	014547	Seal Kit, 1 1/2" x 6" Hydraulic Cylinder	Service kit	1
13	F05009-51	Bolt, 1-8 x 3 1/4" Hex Head Grade 5		2
14	F05010-109	Nut, 1-8 Hex Nylon Lock		2
15	P09143	Fitting, 1/4" NPT x 1/4" JIC Male		4

SECTION 12 ACCESSORIES

LT35HD

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1337	LATHE-MIZER (SEE MANUAL)		
	M1308	LATHE-MIZER TENON KIT (SEE MANUAL)		
	M1624	RS2 RESAW (SEE MANUAL)		
	M903	SHINGLE LAP SIDER (SEE MANUAL)		

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1120	LOG DECK (SEE MANUAL)		

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1120	LOG DECK (SEE MANUAL)		

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1121	INCLINE CONVEYOR (REQUIRES IC2/5-INSTALL) (SEE MANUAL)		
	M1337	LATHE-MIZER (SEE MANUAL)		
	M1308	LATHE-MIZER TENON KIT (SEE MANUAL)		
	M1120	LOG DECK (SEE MANUAL)		
	M903	SHINGLE LAP SIDER (SEE MANUAL)		

SECTION 13 TRAILERS

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1114	ELECTRIC BRAKE (CLASS IV FOR DIESEL ONLY) (SEE MANUAL)		

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1711	ELECTRIC BRAKE (CLASS IV FOR DIESEL ONLY) (SEE MANUAL)		

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M1114	ELECTRIC BRAKE (CLASS IV FOR DIESEL ONLY) (SEE MANUAL)		
	M797	SUPER ELECTRIC BRAKE TRAILER OPTION (SEE MANUAL)		
	M795	SUPER SURGE BRAKE TRAILER OPTION (SEE MANUAL)		

LT35HD

REF	PART #	DESCRIPTION	COMMENTS	QTY.
	M796	ELECTRIC BRAKE TRAILER OPTION (SEE MANUAL)		
	M794	SURGE BRAKE TRAILER OPTION (SEE MANUAL)		

SECTION 14 MISCELLANEOUS

14.1 Replacement Manuals

INDEX

B

bed rails
front/rear 10-1
middle front 10-2
middle rear 10-3
pivot 10-5

blade guide arm 2-5

blade guides
drive side 2-3
idle side 2-1

blade tensioner 3-4

blade wheels
drive side 3-1
idle side 3-2

C

control box 7-3, 7-6
drum switches 7-8
front panel & harnesses 7-9

covers
blade housing 4-6

D

decals
frame 10-9
saw head 4-5

E

engine options 5-1

F

feed chain 9-6

H

hydraulic
hoses 11-1
log clamp 11-14
log loader 11-8
power strip 11-5
side supports (middle) 11-13
toe board 11-16

M

manuals 14-1

O

options, accessories and trailers 6-1, 12-17, 13-1
outfeed table option 10-10

P

power feed 9-3, 9-5

R

rest pin 10-8

S

sawdust chute 4-7
side supports 10-6

T

tensor de hoja 3-3
track rollers
upper 9-1

U

up/down

drive 8-3, 8-10

saw head mount 8-1

Simple Set sensor 8-13, 8-15, 8-16

W

water lube

bottle/tray 4-1, 4-4

bottle/tray (D10, E10, G13 & G15) 4-4